

Safety Light Curtain

F3SJ-B□□□□□25 Series

F3SJ-E□□□□□25 Series

Quick Installation Manual



Relevant manual	Cat. No.
Safety Light Curtain F3SJ-E/B User's Manual	SCHG-732(PNP) SCHG-733(NPN)





Introduction


Thank you for purchasing the F3SJ-E/B Series Safety Light Curtain (hereinafter referred to as the "F3SJ-E/B"). This document is a brief description from wiring to pre-operation checklists / maintenance checklists of F3SJ-E/B. For details, download and read F3SJ-E/B operation manual and user's manual from Omron's website. <https://industrial.omron.us/en/home>

Table of Contents

1. What is Included	1
2. System Components	2
3. Light Curtain Setup Flow	3
4. Function Selection Flow Chart	3
5. Wiring Examples	4
5-1. Auto reset mode, external test used, PNP output	4
5-2. Auto reset mode, external test used, NPN output	4
5-3. EDM used, manual reset mode, external test used, muting function not used, PNP output	5
5-4. EDM used, manual reset mode, external test used, muting function not used, NPN output	5
6. Mounting and Beam Alignment	6
6-1. Mutual Interference Prevention	6
6-2. Distance from Reflective Surfaces	6
6-3. Safety Distance	6
6-4. External dimensions to attach the top/bottom brackets (F39-LJB1) and intermediate brackets (F39-LJB2)	7
6-5. Mounting and Beam Alignment	9
7. Pre-Operation Checklists / Maintenance Checklists	12
Suitability for Use/Contact Information	15


1. What is Included

Product	Pcs & Details														
F3SJ-E□□□□□25 main unit 	Emitter x 1, Receiver x 1 Functional Setting <table border="1"> <thead> <tr> <th>Function</th> <th>Factory Default Setting</th> </tr> </thead> <tbody> <tr> <td>External Test</td> <td>PNP: Enabled when Vs-3V to Vs*1 applied NPN: Enabled when 0V to 3V applied</td> </tr> </tbody> </table> <p>*1 Vs here means the voltage value under use environment.  For details, refer to <i>F3SJ-E/B series user's manual</i>.</p>	Function	Factory Default Setting	External Test	PNP: Enabled when Vs-3V to Vs*1 applied NPN: Enabled when 0V to 3V applied										
Function	Factory Default Setting														
External Test	PNP: Enabled when Vs-3V to Vs*1 applied NPN: Enabled when 0V to 3V applied														
F3SJ-B□□□□□25 main unit 	Emitter x 1, Receiver x 1 Functional Settings <table border="1"> <thead> <tr> <th>Function</th> <th>Setting</th> </tr> </thead> <tbody> <tr> <td>External Test</td> <td>PNP: Enabled when Vs-3V to Vs*1 applied NPN: Enabled when 0V to 3V applied</td> </tr> <tr> <td>Interlock</td> <td>Switching between manual reset mode and auto reset mode is available by wiring</td> </tr> <tr> <td>External Device Monitoring (EDM)</td> <td>Switching between enable/disable is available by wiring</td> </tr> <tr> <td>Auxiliary Output</td> <td>In case of Basic System Control Output Information (Output Inversion Function: Enabled) In case of Muting System Muting/Override Output Information (external indicator connected)</td> </tr> <tr> <td>Muting</td> <td>Enabled when muting Key Cap F39-CN10 attached</td> </tr> <tr> <td>Override</td> <td>Enabled when muting Key Cap F39-CN10 attached</td> </tr> </tbody> </table> <p>*1 Vs here means the voltage value under use environment.  For details, refer to <i>F3SJ-E/B series user's manual</i>.</p>	Function	Setting	External Test	PNP: Enabled when Vs-3V to Vs*1 applied NPN: Enabled when 0V to 3V applied	Interlock	Switching between manual reset mode and auto reset mode is available by wiring	External Device Monitoring (EDM)	Switching between enable/disable is available by wiring	Auxiliary Output	In case of Basic System Control Output Information (Output Inversion Function: Enabled) In case of Muting System Muting/Override Output Information (external indicator connected)	Muting	Enabled when muting Key Cap F39-CN10 attached	Override	Enabled when muting Key Cap F39-CN10 attached
Function	Setting														
External Test	PNP: Enabled when Vs-3V to Vs*1 applied NPN: Enabled when 0V to 3V applied														
Interlock	Switching between manual reset mode and auto reset mode is available by wiring														
External Device Monitoring (EDM)	Switching between enable/disable is available by wiring														
Auxiliary Output	In case of Basic System Control Output Information (Output Inversion Function: Enabled) In case of Muting System Muting/Override Output Information (external indicator connected)														
Muting	Enabled when muting Key Cap F39-CN10 attached														
Override	Enabled when muting Key Cap F39-CN10 attached														
Operation Manual	3														
Quick Installation Manual (this document)	1														


 For ratings/specifications, input/output circuit, LED indicator status and troubleshooting, refer to *Safety Light Curtain F3SJ-E/B Series User's Manual*.

2. System Components

F3SJ-E




1. Top-beam-state indicator (Blue)
2. Stable-state indicator (Green)
3. ON/OFF-state indicator (Green/Red)
4. Lockout indicator (Red)
5. Power indicator (Green)
6. Test indicator (Green)
10. Bottom-beam-state indicator (Blue)




1. Top-beam-state indicator (Blue)
2. Stable-state indicator (Green)
3. ON/OFF-state indicator (Green/Red)
4. Lockout indicator (Red)
5. Communication indicator (Green)
6. Configuration indicator (Green)
7. Internal error indicator (Red)
10. Bottom-beam-state indicator (Blue)

F3SJ-B




1. Top-beam-state indicator (Blue)
2. Stable-state indicator (Green)
3. ON/OFF-state indicator (Green/Red)
4. Lockout indicator (Red)
5. Power indicator (Green)
6. Test indicator (Green)
7. Muting error indicator (Green)
8. Muting input 1 indicator (Green)
9. Muting input 2 indicator (Green)
10. Bottom-beam-state indicator (Blue)



1. Top-beam-state indicator (Blue)
2. Stable-state indicator (Green)
3. ON/OFF-state indicator (Green/Red)
4. Lockout indicator (Red)
5. Communication indicator (Green)
6. Configuration indicator (Green)
7. Internal error indicator (Red)
8. Interlock indicator (Yellow)
9. External device monitoring indicator (Green)
10. Bottom-beam-state indicator (Blue)

3. Light Curtain Setup Flow



4. Function Selection Flow Chart


F3SJ-E

Wiring depends on the function to be used. Shown below are functions available for F3SJ-E.


- External Test Function

F3SJ-B

Required system configuration depends on functions to be used. Use the following flow chart to determine the system.



*1 Muting Key Cap (F39-CN10) is necessary.

 For configuration to use the muting function, refer to *F3SJ-E/B series user's manual*.




5.Wiring Examples



For wiring examples of input/output circuit and other wiring examples than below, refer to *F3SJ-E/B series user's manual*.

F3SJ-E

5-1. Auto reset mode, external test used, PNP output




S1: External test/lockout reset switch (connect to 0V if the switch is not necessary)

*1: Use a switch for micro loads (Input specifications: 24V, 1.0mA or less)

*2: For available controller to connect, refer to *F3SJ-E/B series user's manual*.

*3: The safety controller and F3SJ-E/B must share the power supply or power supply common terminal.

5-2. Auto reset mode, external test used, NPN output



S1: External test/lockout reset switch (connect to 24V if the switch is not necessary)


*1: Use a switch for micro loads (Input specifications: 24V, 1.0mA or less)

*2: For available controller to connect, refer to *F3SJ-E/B series user's manual*.

*3: The safety controller and F3SJ-E/B must share the power supply or power supply common terminal.

F3SJ-B


5-3. EDM used, manual reset mode, external test used, muting function not used, PNP output



- S1 : External test switch (connect to 0 V if a switch is not required)
 S2 : Interlock/lockout reset switch
 KM1, KM2 : Safety relay with force-guided contact (G7SA) or magnetic contactor
 K1 : Load or PLC, etc. (for monitoring)

- *1 Use a switch for micro loads (Input specifications: 24V, 1.0mA or less)
 *2 F3SJ can work even if K1 is not connected.

5-4. EDM used, manual reset mode, external test used, muting function not used, NPN output



- S1 : External test switch (connect to 24 V if a switch is not required)
 S2 : Interlock/lockout reset switch
 KM1, KM2 : Safety relay with force-guided contact (G7SA) or magnetic contactor
 K1 : Load or PLC, etc. (for monitoring)

- *1 Use a switch for micro loads (Input specifications: 24V, 1.0mA or less)
 *2 F3SJ can work even if K1 is not connected.



6. Mounting and Beam Alignment



For brackets other than top/bottom brackets (F39-LJB1) and intermediate brackets (F39-LJB2) as well as external dimensions and mounting, refer to *F3SJ-E/B series user's manual*.

6-1. Mutual Interference Prevention

■ Series Connection

Up to three sets of F3SJ-Bs can be series-connected. Series connection allows them to be used as a safety light curtain, requiring only one set to be wired to a controller and preventing mutual interference.

If any one set of series-connected F3SJ-B is blocked, both of the safety outputs turn OFF. The indication LED for each F3SJ-B turns ON separately.

- Number of connections: Up to three sets
- Total number of beams: Up to 192 beams
- Connection cable length between two F3SJ-Bs in series connection: 7 m max.


■ No Connection

Mutual interference is prevented in up to 3 sets, using interference light avoidance algorithm. If 4 or more sets of F3SJ-E/B are installed and are not connected to each other, arrange them so that mutual interference does not occur. If 2 sets are installed near each other, reflection from the surface of the F3SJ-E/B may cause mutual interference. When mutual interference occurs, the safety outputs are turned OFF in a moment or the F3SJ-E/B enters lockout. Combining countermeasures 1 to 4 shown below is effective.

1. Install a physical barrier between 2 sets
2. Alternate the direction of emission between 2 sets (alternation) If 2 sets are installed near each other, reflection from the surfaces may cause mutual interference. For such a case, it can be improved by reducing operating range through the setting tool (see Step 3).
3. Reducing operating range (setting change by the setting tool is required)
4. Keep sufficient distance between the F3SJ-E/Bs so that mutual interference does not occur

6-2. Distance from Reflective Surfaces

Install the sensor system at distance D or further from highly reflective surfaces such as metallic walls, floors, ceilings, or workpieces, as shown below.



Distance between an emitter and a receiver (operating range L)	Allowable installation distance D
0.2 to 3 m	0.13 m
More than 3 m	$L/2 \times \tan 5^\circ = L \times 0.044$ (m)

6-3. Safety Distance

How to calculate the safety distance specified by International Standard ISO 13855(European standard EN ISO 13855)(Reference)

■ If a person approaches the detection zone of the F3SJ-E/B perpendicularly


$S = K \times T + C$. . . Formula (1)

- S: Safety distance
 - K: Approach speed to the detection zone
 - T: Total response time of the machine and F3SJ-E/B
 - C: Additional distance calculated by the detection capability of the F3SJ-E/B
- <System that has detection capability of 30mm or less>

Use $K = 2,000\text{mm/s}$ and $C = 8 \times (d - 14\text{mm})$ in formula (1) for the calculation.

$S = 2,000\text{mm/s} \times (T_m + T_s) + 8 \times (d - 14\text{mm})$

- S = Safety distance (mm)
- T_m = Machine's response time (s)
- T_s = Response time of the F3SJ-E/B from ON to OFF (s)
- d = Detection capability of the F3SJ-E/B (mm)



Please refer to the user's manual for calculation of following safety distance.

■ Possible circumventing by reaching over the detection zone

■ In case of horizontal approach of a human body to F3SJ-E/B's detection zone

■ How to calculate the safety distance specified by American standard ANSI B11.19(reference)



6-4. External dimensions to attach the top/bottom brackets (F39-LJB1) and intermediate brackets (F39-LJB2)

■ Dimensions (Check position)

[Backside mounting]

Step1

Check position




Step2

Mount



Step3

Align beams



[Unit : mm]

Dimensions A to E and P

A	C+69
B	C+42.2
C	4-digit number of the type name (protective height)
D	C-45
E	Depends on the protective height. See the table below.
P	20

Dimensions E

Protective height	Number of Intermediate Brackets	Dimensions E
0185 to 1105	0	-
1185 to 1345	1	C/2 max.
1425 to 2065	2	C/3 max.

* Value E must be 700 mm or less when not using value E obtained from the calculation above.



If the protective height exceeds 1105mm, use the intermediate brackets as many as and on the positions specified in the dimensional drawing. Otherwise ratings/specifications cannot be satisfied.




If load is applied to the sensor unit in your environment, add intermediate bracket(s).



■ Dimensions (Check position)

[Side mounting]



Step1

Check
position

Step2

Mount



Step3

Align
beams

Dimensions A to E

A	C+69
B	C+42.2
C	4-digit number of the type name (protective height)
D	C-45
E	Depends on the protective height. See the table below.

Dimensions E

Protective height	Number of Intermediate Brackets	Dimensions E
0185 to 1105	0	-
1185 to 1345	1	C/2 max.
1425 to 2065	2	C/3 max.

* Value E must be 700 mm or less when not using value E obtained from the calculation above.



If the protective height exceeds 1105mm, use the intermediate brackets as many as and on the positions specified in the dimensional drawing. Otherwise ratings/specifications cannot be satisfied.



If load is applied to the sensor unit in your environment, add intermediate bracket(s).



For mounting brackets other than top/bottom brackets (F39-LJB1) and intermediate brackets (F39-LJB2) as well as external dimensions, refer to *F3SJ-E/B series user's manual*.



6-5. Mounting and Beam Alignment



Mounting brackets are not included in the product. You must purchase them separately.

Step1

Check
position

Step2


Mount




Step3

Align
beams

1. Loosen the intermediate mounting bracket bolts.



2. Lightly tighten the intermediate mounting bracket to the case.






For position and number of intermediate mounting brackets, refer to 6-4 of this document.



3. Attach the top/bottom brackets to the case.





<Backside mounting>

Hexagon socket head cap screws (M3 x 6)
(Recommended tightening torque: 0.54Nm)



<Side mounting>

Hexagon socket head cap screws (M3 x 6)
(Recommended tightening torque: 0.54Nm)



Step1

Check position



Step2

Mount




Step3

Align beams

4. Fix the unit on the wall.


<Backside mounting>

Hexagon socket head cap screw
(M3 x 12)
(Recommended tightening torque: 0.54Nm)





<Side mounting>

Hexagon socket head cap screw
(M3 x 12)
(Recommended tightening torque: 0.54Nm)



Hexagon socket head cap screw
(M3 x 12)
(Recommended tightening torque: 0.54Nm)

Wall-mounting screw (M5)




Wall-mounting screws are not included.




5. Align beams based on the indicators.

- Step1
Check position
↓
Step2
Mount
↓
Step3
Align beams



The angle adjustment range of intermediate mounting bracket (F39-LJB2) is +/-30 degrees.

6. Fully tighten the hexagon socket screws (M3 x 8/M3 x 18) of top/bottom brackets and intermediate brackets that were lightly tightened.



Please do not tighten each screw one by one. Fully tighten all of them in a balanced manner at all places.



Tightening with torque exceeding the recommended value too much may lead to a failure.



7. Pre-Operation Checklists / Maintenance Checklists

After wiring, mounting and beam alignment are done, check the operation of the F3SJ-E/B.

Pre-Operation Checklists

After installation, the highest level administrator must use the following checklist to verify the operation, placing a check mark in each of the boxes.

■ Checklists

- Installation Condition Check

- The machine itself does not prevent the operation of safety functions such as stopping.
- The hazardous part of a machine cannot be reached without passing through the detection zone of the F3SJ-E/B.
- The system is configured so that the F3SJ-E/B can always detect a worker who is working in the hazardous zone.
- The interlock reset switch is installed in a location that provides a clear view of the entire hazardous zone and it cannot be activated from within the hazardous zone.
- Safety distance has been calculated. Calculated distance: $S = () \text{ mm}$
- The actual distance is equal to or greater than the calculated distance. Actual distance = $() \text{ mm}$
- Reflective surfaces are not installed in prohibited zones.
- Not installed in a reflective configuration.
- When muting function is used, a muting sensor must be installed so that muting state should not occur when a human body enters a detection zone of F3SJ-E/B by mistake.
- When muting function is used, a muting sensor must be installed so that muting state should not occur when a human body enters a hazardous zone of a machine.
- When muting function is used, muting state can be checked from where a worker operates or adjust the machine.
- A muting sensor consists of two independent devices.
- Not used in flammable or explosive atmosphere.

- Wiring Check Before Power Is Turned ON

- Sharing the power supply with other devices may cause the F3SJ-E/B to be affected by noise or voltage drop. It is recommended that this safety component use a dedicated power supply but do not share with other devices.
- The power supply unit provides 24 VDC while complying with the EMC Directive, Low Voltage Directive, output holding specification.
- The power supply polarity is not connected in reverse.
- Emitter/receiver cables are properly connected to the respective emitters/receivers.
- Double insulation is provided between input/output and hazardous voltage (commercial power source, etc.).
- Outputs are not short-circuited to the following line.
F3SJ-E□□□□P□□, F3SJ-B□□□□P□□: +24V line
F3SJ-E□□□□N□□, F3SJ-B□□□□N□□: 0V line
- Loads are not connected to the following line.
F3SJ-E□□□□P□□, F3SJ-B□□□□P□□: +24V line
F3SJ-E□□□□N□□, F3SJ-B□□□□N□□: 0V line
- All lines are not connected to commercial power source.
- Model of emitter and receiver must be the same.
- When two or more sets of F3SJ-E/Bs are used, they are series-connected or mutual interference prevention measures are taken.
- When two or more sets of F3SJ-Bs are used in series connection, a PNP type must not be connected to an NPN type, and vice versa.
- A secondary sensor farthest from its power supply has either of the following:
 - Cap
 - Key cap for muting
- Neither connector nor bracket must be loose.
- Auxiliary output must not be used as safety output.
- Power supply's 0 V must be grounded for F3SJ-E□□□□P□□, F3SJ-B□□□□P□□.
- Power supply's 24 V must be grounded for F3SJ-E□□□□N□□, F3SJ-B□□□□N□□.



- Wiring must not be bent, cracked, nor damaged.


-Operation Check While the Machine Is Stopped

- The test rod is not deformed.

Depending on the unit's model and settings of floating blanking function, detection capability may vary. Use a test rod with an appropriate diameter for inspection. The model name of test rod is as follows.

Model name	Diameter
F39-TRD25	Dia. 25mm

- The sensor can detect a test rod wherever it is in the detection zone. In other words, when a test rod is inserted into the detection zone, the stable-state indicators (STB) turn off and the ON/OFF output-state indicators turn red.



- When the external test function is used:

The OFF-state indicator turns ON when the test input line is short-circuited in the following voltage.

F3SJ-E□□□□P25, F3SJ-B□□□□P25: Vs-3V to Vs

F3SJ-E□□□□N25, F3SJ-B□□□□N25: 0V to 3V

- When the external device monitoring function is used:

When the F3SJ-B is blocked and the external device monitoring input terminal is open, it enters a lockout state.

- When the manual reset function is used:

After the F3SJ-B is turned ON, the ON/OFF-state indicators must remain red, even if the F3SJ-B is not blocked. The reset input must turn the ON/OFF-state indicators to green. After that, when the F3SJ-B is blocked and returned to unblocked state when the ON/OFF-state indicators are green, the ON/OFF-state indicators remain red. The reset input must turn the ON/OFF-state indicators to green.

- When using muting lamp:

Under muting state, a signal that indicates muting state is output to the auxiliary output.

Under override state, a signal that indicates override state is output to the auxiliary output.

-Checking that Hazardous Parts Stop While the Machine Operates

- The hazardous parts stop immediately when a test rod is inserted into the detection zone at three positions: "directly in front of the emitter", "directly in front of the receiver", and "between the emitter and receiver". (Use the appropriate test rod.)
- The hazardous parts remain stopped as long as the test rod is in the detection zone.
- The hazardous parts stop when the power of the F3SJ-E/B is turned OFF.
- The actual response time of the whole machine is equal to or less than the calculated value.

Maintenance Checklists

To ensure safety, keep a record of the inspection results. When the user is a different person from those who installed or designed the system, he/she must be properly trained for maintenance.

■ Checklists

-Inspection at Startup and When Changing Operators

- There is no approach route other than through the detection zone of the F3SJ-E/B.
- Part of the operator's body always remains in the detection zone of the F3SJ-E/B when working around the machine's hazardous part.
- The actual safety distance is equal to or greater than the calculated value.
- There must be no dirt on or damage to the optical surface and spatter protection cover (F39-HB□□□□, sold separately) of the F3SJ-E/B.



- ON/OFF-state indicators turn red when the test input line is short-circuited to in the following voltage.
F3SJ-E□□□□P25, F3SJ-B□□□□P25: Vs-3V to Vs
F3SJ-E□□□□N25, F3SJ-B□□□□N25:0V to 3V
 - When muting lamp is used, a muting lamp must be clear and free of dirt or degradation.
 - The test rod is not deformed.
 - When the manual reset function is used:
After the F3SJ-B is turned ON, the ON/OFF-state indicators must remain red, even if the F3SJ-B is not blocked. The reset input must turn the ON/OFF-state indicators to green. After that, when the ON/OFF-state indicators are green, block the F3SJ-B and return it to unblocked state. The ON/OFF-state indicators remain red. The reset input must turn the ON/OFF-state indicators to green.
 - When the power of the F3SJ-E/B is turned ON while nothing is in the detection zone, it must operate as follows:
When auto reset is used: The power indicator and ON/OFF-state indicators turn green within 2 seconds after the F3SJ-B is turned ON. When manual reset is used: The power indicator turns green and the ON/OFF-state indicators turn red within 2 seconds after the F3SJ-B is turned ON.
 - When the power of the F3SJ-E is turned ON while nothing is in the detection zone, it must operate as follows:
The power indicator and the ON/OFF-state indicator turn to green within 2 seconds after the power is turned ON.
 - Nothing should exist in the detection zone and stable-state indicators must turn ON at power on.
 - The test rod is detected when it is moved around in the detection zone as shown in the diagram of Pre-Operation Checklists.
In other words, when a test rod is inserted into the detection zone, the stable-state indicators (STB) turn off and the ON/OFF-state indicators turn red.
 - When muting function is used, installation condition of muting sensor must not be changed.
 - When muting function is used, muting state can be checked from where a worker operates or adjust the machine.
 - Neither connector nor bracket must be loose.
- Checking that Hazardous Parts Stop While the Machine Operates
- The hazardous parts are movable when nothing is in the detection zone.
 - The hazardous parts stop immediately when a test rod is inserted into the detection zone at three positions: "directly in front of the emitter", "directly in front of the receiver", and "between the emitter and receiver". (Use the appropriate test rod.)
 - The hazardous parts remain stopped as long as the test rod is in the detection zone.
 - The hazardous parts stop when the power of the F3SJ-E/B is turned OFF while nothing is in the detection zone.
- Items to Inspect Every 6 Months or When Machine Settings Are Changed
- In addition to inspection item at operation start, following items must also be verified.
- The outputs of the F3SJ-E/B and the machine are properly wired.
 - The total number of times that the control relays/contactors have switched is significantly lower than their design lives.
 - There is no disturbance light.
 - When F3SJ-B is connected again, a secondary sensor farthest from its power supply has either of the followings:
 - Cap
 - Key cap for muting
 - Power supply's 0 V must be grounded for F3SJ-E□□□□P□□, F3SJ-B□□□□P□□.
 - Power supply's 24 V must be grounded for F3SJ-E□□□□N□□, F3SJ-B□□□□N□□.
 - Wiring must not be bent, cracked, nor damaged.

Suitability for Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

See also Product catalog for Warranty and Limitation of Liability.

OMRON Corporation Industrial Automation Company (Manufacturer)

Shiokoji Horikawa, Shimogyo-ku, Kyoto, 600-8530 JAPAN

Contact: www.ia.omron.com

Regional Headquarters

■ **OMRON EUROPE B.V.** (Representative and Importer in EU)
Wegalaan 67-69, NL-2132 JD Hoofddorp
THE NETHERLANDS
Tel: (31)-2356-81-300 / FAX: (31)-2356-81-388

■ **OMRON ASIA PACIFIC PTE. LTD.**
No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967
Tel: (65) 6835-3011 / Fax: (65) 6835-2711

■ **OMRON ELECTRONICS LLC**
2895 Greenspoint Parkway, Suite 200
Hoffman Estates, IL 60169 U.S.A.
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

■ **OMRON (CHINA) CO., LTD.**
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222 / Fax: (86) 21-5037-2200

In the interest of product improvement, specifications are subject to change without notice.

セーフティライトカーテン
F3SJ-B□□□□□25シリーズ
F3SJ-E□□□□□25シリーズ

クイックインストールマニュアル



関連マニュアル	マニュアル番号
セーフティライトカーテン F3SJ-E/B ユーザーズマニュアル	SCHG-732(PNP) SCHG-733(NPN)

はじめに

このたびはセーフティライトカーテン形 F3SJ-E/B シリーズ（以下 F3SJ-E/B と呼びます）をお買い上げいただき、ありがとうございます。

本書は F3SJ-E/B の配線から動作チェックまでの流れを示した簡易説明書です。





詳細については F3SJ-E/B の取扱説明書、ユーザーズマニュアルを当社ウェブサイトからダウンロードし、よくお読みください。


<http://www.fa.omron.co.jp>

目次

1. 同梱物のご確認	1
2. 各部の名称	2
3. ライトカーテンセットアップの流れ	3
4. 機能選択フローチャート	3
5. 配線例	4
5-1. オートリセットモード、外部テスト使用、PNP 出力	4
5-2. オートリセットモード、外部テスト使用、NPN 出力	4
5-3. EDM 使用、マニュアルリセットモード、外部テスト使用、ミューティング機能未使用、PNP 出力	5
5-4. EDM 使用、マニュアルリセットモード、外部テスト使用、ミューティング機能未使用、NPN 出力	5
6. 取り付け・光軸調整	6
6-1. 上下金具（形 F39-LJB1）、中間金具（形 F39-LJB2）を取り付ける場合の外形寸法	6
6-2. 取り付け方法と光軸調整	8
7. 動作チェック	11
ご承諾事項 / お問い合わせ先	11



1. 同梱物のご確認

製品	数量、内容															
形F3SJ-E□□□□□25本体 	投光器×1、受光器×1 機能設定 <table border="1"> <thead> <tr> <th>機能</th> <th>出荷時設定</th> </tr> </thead> <tbody> <tr> <td>外部テスト</td> <td>PNP : Vs-3V~Vs*1印加時有効 NPN : 0V~3V印加時有効</td> </tr> </tbody> </table> <p>*1ここのVsとは使用環境での電圧値です。  詳細については F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。</p>	機能	出荷時設定	外部テスト	PNP : Vs-3V~Vs*1印加時有効 NPN : 0V~3V印加時有効											
機能	出荷時設定															
外部テスト	PNP : Vs-3V~Vs*1印加時有効 NPN : 0V~3V印加時有効															
形F3SJ-B□□□□□25本体 	投光器×1、受光器×1 各種機能設定 <table border="1"> <thead> <tr> <th>機能</th> <th>設定</th> </tr> </thead> <tbody> <tr> <td>外部テスト</td> <td>PNP : Vs-3V~Vs*1印加時有効 NPN : 0V~3V印加時有効</td> </tr> <tr> <td>インターロック</td> <td>配線にてマニュアルリセットモード、オートリセットモード切り替え可能</td> </tr> <tr> <td>外部リレーモニタ(EDM)</td> <td>配線にて有効/無効の切り替え可能</td> </tr> <tr> <td rowspan="2">補助出力</td> <td>ベーシックシステム時 制御出力情報(出力反転機能 : 有効)</td> </tr> <tr> <td>ミューティングシステム時 ミューティング/オーバーライド出力情報 (外部表示灯を接続)</td> </tr> <tr> <td>ミューティング</td> <td>ミューティング用キーキャップ形F39-CN10装着時有効</td> </tr> <tr> <td>オーバーライド</td> <td>ミューティング用キーキャップ形F39-CN10装着時有効</td> </tr> </tbody> </table> <p>*1ここのVsとは使用環境での電圧値です。  詳細については F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。</p>	機能	設定	外部テスト	PNP : Vs-3V~Vs*1印加時有効 NPN : 0V~3V印加時有効	インターロック	配線にてマニュアルリセットモード、オートリセットモード切り替え可能	外部リレーモニタ(EDM)	配線にて有効/無効の切り替え可能	補助出力	ベーシックシステム時 制御出力情報(出力反転機能 : 有効)	ミューティングシステム時 ミューティング/オーバーライド出力情報 (外部表示灯を接続)	ミューティング	ミューティング用キーキャップ形F39-CN10装着時有効	オーバーライド	ミューティング用キーキャップ形F39-CN10装着時有効
機能	設定															
外部テスト	PNP : Vs-3V~Vs*1印加時有効 NPN : 0V~3V印加時有効															
インターロック	配線にてマニュアルリセットモード、オートリセットモード切り替え可能															
外部リレーモニタ(EDM)	配線にて有効/無効の切り替え可能															
補助出力	ベーシックシステム時 制御出力情報(出力反転機能 : 有効)															
	ミューティングシステム時 ミューティング/オーバーライド出力情報 (外部表示灯を接続)															
ミューティング	ミューティング用キーキャップ形F39-CN10装着時有効															
オーバーライド	ミューティング用キーキャップ形F39-CN10装着時有効															
取扱説明書	3															
クイックインストールマニュアル(本紙)	1															

 定格/性能、入出力回路、LED表示灯の点灯パターン、トラブルシューティングについては、F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。



2. 各部の名称

F3SJ-E




1. 上端入光表示灯 (青)
 2. 安定表示灯 (緑)
 3. ON/OFF出力表示灯 (緑/赤)
 4. ロックアウト表示灯 (赤)
 5. 電源表示灯 (緑)
 6. テスト表示灯 (緑)
 10. 下端入光表示灯 (青)
1. 上端入光表示灯 (青)
 2. 安定表示灯 (緑)
 3. ON/OFF出力表示灯 (緑/赤)
 4. ロックアウト表示灯 (赤)
 5. 通信表示灯 (緑)
 6. 構成表示灯 (緑)
 7. 内部エラー表示灯 (赤)
 10. 下端入光表示灯 (青)

F3SJ-B



1. 上端入光表示灯 (青)
 2. 安定表示灯 (緑)
 3. ON/OFF出力表示灯 (緑/赤)
 4. ロックアウト表示灯 (赤)
 5. 電源表示灯 (緑)
 6. テスト表示灯 (緑)
 7. ミューティングエラー表示灯 (緑)
 8. ミューティング入力表示灯 (緑)
 9. ミューティング入力カ表示灯 (緑)
 10. 下端入光表示灯 (青)
1. 上端入光表示灯 (青)
 2. 安定表示灯 (緑)
 3. ON/OFF出力表示灯 (緑/赤)
 4. ロックアウト表示灯 (赤)
 5. 通信表示灯 (緑)
 6. 構成表示灯 (緑)
 7. 内部エラー表示灯 (赤)
 8. インターロック表示灯 (黄)
 9. 外部リレーモータ表示灯 (緑)
 10. 下端入光表示灯 (青)

3. ライトカーテンセットアップの流れ



4. 機能選択フローチャート


F3SJ-E

使用する機能により配線が変わります。F3SJ-E で使用可能な機能は以下のとおりです。


- ・外部テスト機能

F3SJ-B


使用する機能により必要なシステム構成が変わってきます。以下のフローチャートに従い、どのシステムが必要か決定してください。



*1 ミューティング用キーキャップ(形F39-CN10)が必要です。


 ミューティング機能を使用する場合の構成については、F3SJ-E/Bシリーズユーザーズマニュアルを参照ください。

5. 配線例

 入出力回路および下記以外の配線例については、F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。

F3SJ-E

5-1. オートリセットモード、外部テスト使用、PNP出力




S1：外部テスト/ロックアウトリセットスイッチ(スイッチが不要な場合、0Vに接続)

*1：微小負荷用スイッチ(入力仕様：24V、1.0mA以下)をご使用ください。

*2：接続可能なコントローラにつきましては、F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。

*3：セーフティコントローラとF3SJ-E/Bは電源を共通化するか、電源コモンを共通化してください。

5-2. オートリセットモード、外部テスト使用、NPN出力



S1：外部テスト/ロックアウトリセットスイッチ(スイッチが不要な場合、24Vに接続)


*1：微小負荷用スイッチ(入力仕様：24V、1.0mA以下)をご使用ください。

*2：接続可能なコントローラにつきましては、F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。

*3：セーフティコントローラとF3SJ-E/Bは電源を共通化するか、電源コモンを共通化してください。

F3SJ-B


5-3. EDM 使用、マニュアルリセットモード、外部テスト使用、ミュート機能未使用、PNP 出力



- S1 : 外部テストスイッチ (スイッチが不要な場合、0Vに接続)
 S2 : インターロック / ロックアウトリセットスイッチ
 KM1、KM2 : 強制ガイド接点付きセーフティリレー (形 G7SA) やマグネットコンタクタ
 K1 : 負荷、PLC 等 (モータ用)

- *1 微小負荷用スイッチ (入力仕様 : 24V、1.0mA以下) をご使用ください。
 *2 K1が未接続でも形F3SJは動作します。

5-4. EDM 使用、マニュアルリセットモード、外部テスト使用、ミュート機能未使用、NPN 出力





- S1 : 外部テストスイッチ (スイッチが不要な場合、24Vに接続)
 S2 : インターロック / ロックアウトリセットスイッチ
 KM1、KM2 : 強制ガイド接点付きセーフティリレー (形 G7SA) やマグネットコンタクタ
 K1 : 負荷、PLC 等 (モータ用)

- *1 微小負荷用スイッチ (入力仕様 : 24V、1.0mA以下) をご使用ください。
 *2 K1が未接続でも形F3SJは動作します。

■外形寸法図（取り付け位置確認）

[側面取り付け時]

- Step1
取り付け位置確認
- Step2
取り付け
- Step3
光軸調整



[単位: mm]

寸法A～Eについて

寸法A	C+69
寸法B	C+42.2
寸法C	形式中の4桁の数字 (検出幅)
寸法D	C-45
寸法E	検出幅によって変わります。下表を確認ください。

寸法Eについて

検出幅	中間金具の数	寸法E
0185～1105	0	-
1185～1345	1	C/2以下
1425～2065	2	C/3以下

* 上記計算により得られた値Eを使用しない場合Eは700mm以下とする。

💡 検出幅が1105mmを超える場合、外形寸法図に記載されている規定の数量、位置にしたがって中間金具を使用してください。規定に満たない場合、定格/性能を満たすことができません。

💡 センサ本体に荷重がかかるような使用をされる場合は、中間金具を追加してください。

💡 上下金具(形F39-LJB1)、中間金具(形F39-LJB2)以外の取付金具、外形寸法図については、F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。




6-2. 取り付け方法と光軸調整




取付金具は本体に付属していません。別途購入いただく必要があります。

1. 中間金具のボルトを緩めます。



2. 中間金具をケースに仮締めします。






中間金具取り付け位置、個数については、本紙6-1項参照ください。

Step1
取り付け
位置確認
↓
Step2
取り付け
↓
Step3
光軸調整







3. 上下金具をケースに取り付けます。

<背面取り付け>


Step1
取り付け
位置確認Step2
取り付けStep3
光軸調整

<側面取り付け>






4. 壁面へ固定します。

<背面取り付け>



<側面取り付け>



💡 壁面との取り付けネジは付属していません。



7. 動作チェック

配線、取り付け・光軸調整が終わったら、F3SJ-E/Bの動作チェックを実施してください。



動作チェックはF3SJ-E/Bシリーズユーザーズマニュアル記載のチェックリストに従い実施してください。



トラブルシューティングについては、F3SJ-E/Bシリーズユーザーズマニュアルを参照してください。

ご承諾事項

当社商品は、一般工業製品向けの汎用品として設計製造されています。従いまして、次に掲げる用途での使用を意図しておらず、お客様が当社商品をこれらの用途に使用される際には、当社は当社商品に対して一切保証をいたしません。ただし、次に掲げる用途であっても当社の意図した特別な商品用途の場合や特別の合意がある場合は除きます。

- (a) 高い安全性が必要とされる用途（例：原子力制御設備、燃焼設備、航空・宇宙設備、鉄道設備、昇降設備、娯楽設備、医用機器、安全装置、その他生命・身体に危険が及ぶ用途）
- (b) 高い信頼性が必要な用途（例：ガス・水道・電気等の供給システム、24時間連続運転システム、決済システムほか権利・財産を取扱う用途など）
- (c) 厳しい条件または環境での用途（例：屋外に設置する設備、化学的汚染を被る設備、電磁的妨害を被る設備、振動・衝撃を受ける設備など）
- (d) カタログ等に記載のない条件や環境での用途

* (a) から (d) に記載されている他、本カタログ等記載の商品は自動車（二輪車含む。以下同じ）向けではありません。自動車に搭載する用途には利用しないで下さい。自動車搭載用商品については当社営業担当者にご相談ください。

* 上記は適合用途の条件の一部です。当社のベスト、総合カタログ、データシート等最新版のカタログ、マニュアルに記載の保証・免責事項の内容をよく読んでご使用ください。

オムロン株式会社 インダストリアルオートメーションビジネスカンパニー

●製品に関するお問い合わせ先

お客様相談室

フリーダイヤル **0120-919-066**

携帯電話・PHS・IP電話などではご利用いただけませんので、下記の電話番号へおかけください。

電話 **055-982-5015** (通話料がかかります)

■営業時間：8:00～21:00

■営業日：365日

●FAXやWebページでもお問い合わせいただけます。

FAX **055-982-5051** / www.fa.omron.co.jp

●その他のお問い合わせ

納期・価格・サンプル・仕様書は貴社のお取引先、または貴社担当オムロン販売員にご相談ください。オムロン制御機器販売店やオムロン販売拠点は、Webページでご案内しています。