

Cat. No. Z136-E1-1

# **V530-R150**

## **2-Dimensional Code Reader**

# **OPERATION MANUAL**

The OMRON logo is displayed in a bold, black, sans-serif font. The letter 'O' is a solid circle, while the letters 'M', 'R', 'O', and 'N' have a distinctive horizontal line through their middle sections.

**V530-R150**  
**2-Dimensional Code Reader**  
**Operation Manual**

*Produced July 1999*

## Notice:

OMRON products are manufactured for use according to proper procedures by a qualified operator and only for the purposes described in this manual.

The following conventions are used to indicate and classify precautions in this manual. Always heed the information provided with them. Failure to heed precautions can result in injury to people or damage to property.

-  **DANGER** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
-  **WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
-  **Caution** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

## Visual Aids

The following headings will help you locate different types of information.

**Note** Indicates information of particular interest for efficient and convenient operation of the product.

→ Indicates pages where additional information can be found.

**1** Indicates a procedure. The step numbers in the procedure correspond to the numbers in any related illustrations.

## Notation

### Model Name

This product comes in two different models: V530-R150E (input/output type: NPN) and V530-R150EP (input/output type: PNP). In this manual, both models are referred to under the model number “V530-R150.”

### Screen Messages

In this manual, screen messages are given in bold/italic.

E.g.: ***Register***

## © OMRON, 1999

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

# TABLE OF CONTENTS

## PRECAUTIONS .....

- 1 Safety Precautions .....
- 2 General Precautions .....
- 3 Installation Precautions .....
- 4 Package Contents .....

## SECTION 1

### Features .....

- 1-1 Overview of V530-R150 Application .....
- 1-2 Functions .....
- 1-3 Trigger Inputs and Outputs .....

## SECTION 2

### Installation .....

- 2-1 Component Names and Functions .....
- 2-2 Connections .....
- 2-3 Power Supply and Ground .....
- 2-4 Camera .....
- 2-5 CCTV Lens .....
- 2-6 Lighting .....
- 2-7 Mounting the Controller .....

## SECTION 3

### Terminal Blocks .....

- 3-1 Specifications .....
- 3-2 Trigger Input and Output Format .....
- 3-3 Timing Chart .....
- 3-4 System Examination .....

## SECTION 4

### RS-232C .....

- 4-1 Specifications .....
- 4-2 Communication Settings .....
- 4-3 Trigger Inputs and Output Format .....
- 4-4 FCS Calculation .....
- 4-5 Connection Examples .....

# TABLE OF CONTENTS

## SECTION 5

### Operations .....

- 5-1 Menu Operations .....
- 5-2 Menu Tree .....
- 5-3 STEP 1 Starting .....
- 5-4 STEP 2 Setting Reading Conditions .....
- 5-5 STEP 3 Checking Reading .....
- 5-6 STEP 4 Starting Code Reading .....
- 5-7 STEP 5 Quitting .....

## SECTION 6

### Functions and Operations .....

- 6-1 Menu Registration .....
- 6-2 SET (Setting) Mode .....
- 6-3 MON (Monitor) Mode .....
- 6-4 RUN Mode .....
- 6-5 System .....
- 6-6 Scenes .....
- 6-7 Saving to Flash Memory .....

## SECTION 7

### Regular Inspections .....

## SECTION 8

### Specifications/Dimensions .....

- 8-1 V530-R150 2-Dimensional Code Reader Controller ..
- 8-2 Console .....
- 8-3 Camera .....
- 8-4 Cables .....
- 8-5 Video Monitor .....

## SECTION 9

### Troubleshooting .....

- 9-1 Troubleshooting .....
- 9-2 Error Codes and Remedies .....

## Appendices

- A ASCII Codes .....
- B FCS Check Program Examples (BASIC) .....
- C Data Capacity Tables .....

## Index .....

## Revision History .....

# About this Manual:

This manual describes the features, specifications and operation of the V530-R150 2-Dimensional Code Reader and includes the following sections.

**Section 1** gives an overview of the features, applications and basic configurations for the V530-R150 2-Dimensional Code Reader.

**Section 2** describes the different parts of the V530-R150 2-Dimensional Code Reader, and details the connections and other procedures necessary for installation.

**Section 3** describes the specifications, procedures, inputs and outputs used when operating the V530-R150 2-Dimensional Code Reader via terminal blocks.

**Section 4** describes the specifications, procedures, inputs and outputs used when operating the V530-R150 2-Dimensional Code Reader via RS-232C.

**Section 5** gives an overview of menu operations for the V530-R150 2-Dimensional Code Reader and explains the procedures required to perform basic operations.

**Section 6** gives details of the functions and operations possible with the V530-R150 2-Dimensional Code Reader, including the procedures necessary for communications with external devices.

**Section 7** gives basic maintenance procedures and inspection items for the V530-R150 2-Dimensional Code Reader.

**Section 8** gives specifications and dimensions for the component parts of the V530-R150 2-Dimensional Code Reader.

**Section 9** details errors that may occur with the V530-R150 2-Dimensional Code Reader and gives procedures for dealing with those errors.

The **Appendices** provide ASCII codes, examples of FCS check programs, and data capacity tables.



## **WARNING**

Failure to read and understand the information provided in this manual may result in personal injury or death, damage to the product, or product failure. Please read each section in its entirety and be sure you understand the information provided in the section and related sections before attempting any of the procedures or operations given.

# PRECAUTIONS

This section provides general precautions for using the V530-R150 2-Dimensional Code Reader.

**The information contained in this section is important for the safe and reliable application of the V530-R150 2-Dimensional Code Reader. You must read this section and understand the information contained before attempting to set up or operate a V530-R150 2-Dimensional Code Reader.**

1 Safety Precautions .....	
2 General Precautions .....	
3 Installation Precautions .....	
4 Package Contents .....	

# 1 Safety Precautions

 **WARNING** Cover the terminal blocks with the Terminal Block Protection covers. Uncovered terminal blocks can result in electric shock.



 **WARNING** Use DC power supplies with safe extra low-voltage circuits on the secondary side for the main V530-R150 power supply and power supplies for the terminal blocks. Excessively high voltages can result in electric shock.



 **Caution** Do not touch fluorescent or halogen light while the power is ON or immediately after the power is turned OFF. These lights generate heat and can cause burns.



The following must be followed to ensure the safety.

 **Caution** Do not use the V530-R150 in environments with flammable or explosive gases.

 **Caution** Install the V530-R150 away from high-voltage equipment or motors to ensure safety during operation and maintenance.

 **Caution** Use the power supply cables and crimp terminals of specified sizes.

 **Caution** Use at the power supply voltages specified in this manual.

 **Caution** Be sure to securely tighten the screws when mounting V530-R150 components.

 **Caution** Do not dismantle, repair or modify any V530-R150 components.

 **Caution** Dispose of V530-R150 components as industrial waste.

 **Caution** To prevent damage from static electricity, use a wrist strap or another device for preventing electrostatic charges when touching terminals or signal line.

 **Caution** Do not turn OFF the power while a message is being displayed indicating that processing is being performed. Data in memory will be destroyed, and the V530-R150 may not operate correctly the next time it is started. Please note that the V530-R150 can not restart if the power is turned OFF while the start up message is on a screen.

## 2 General Precautions

The user must operate the product according to the performance specifications described in the operation manuals.

Before using the product under conditions which are not described in the manual or applying the product to unclear control systems, railroad systems, aviation systems, vehicles, combustion systems, medical equipment, amusement machines, safety equipment, and other systems, machines, and equipment that may have a serious influence on lives and properly if used improperly, consult your OMRON representative.

Make sure that the ratings and performance characteristics of the product are sufficient for the systems, machines, and equipment, and be sure to provide the systems, machines, and equipment with double safety mechanisms.

## 3 Installation Precautions

The V530-R150 is highly reliable and resistant to most environmental factors. The following guidelines, however, must be followed to ensure reliability and optimum use of the V530-R150.

### Components

Be sure to use the Camera, Camera Cable, and Console designed for the V530-R150.

- Camera (F150-S1)
- Camera Cable (F150-VS)
- Camera Console (F150-KP)

**Installation Site**

Do not install the V530-R150 in locations subject to the following conditions.


- Ambient temperatures outside of 0 to +40°C for the F300-M09 Video Monitor (recommended monitor) or outside of +50°C for all other V530-R150 components.
- Condensation due to rapid temperature fluctuations
- Relative humidities outside 35 to 85%
- Corrosive or flammable gases
- Dust, salt, or iron particles
- Direct vibration or shock
- Direct sunlight
- Water, oil, or chemical fumes or spray

**Installation**

**Orientation of Controller**


To improve heat dissipation, install the controller in the following orientation only:

**CORRECT**




Do not install the controller in the orientations shown in the following diagram.

**INCORRECT**




**INCORRECT**



**Ambient Temperature**

- Maintain a minimum clearance of 50mm above and below V530-R150 components to improve air circulation.
- Do not install V530-R150 components immediately above strong heat sources, such as heaters, transformers, or large-capacity resistors.
- Do not let the ambient operating temperature exceed 50°C.
- Provide a forced-air fan or air conditioning if the ambient temperature might exceed 50°C.




**Noise Resistance**

Use the following measures to help increase noise resistance.

- Do not install V530-R150 components in a cabinet containing high-voltage equipment.

- Do not install V530-R150 components within 200 mm of power cables.



## Cables

Always turn OFF the power before connecting or disconnecting cables.

## Cameras

The camera's case is connected to the 0V line in the internal circuits.

Heed the following precautions to prevent noise interference.

- Do not ground the camera.
- Do not remove the base attached to the camera.
- Do not remove the core attached to the F150-VS camera cable.

## Video Monitor

(When using the recommended F300-M09)

Heed the following precautions to prevent noise interference if the video monitor case is metallic, because it is connected to the 0V line in the internal circuits.

- Do not ground the video monitor.
- Do not ground the metallic part of the connector.
- Secure the video monitor with plastic screws if it is being mounted to a metallic surface.

## 2-Dimensional Code



- The blank margin (quiet zone) is necessary around 2-dimensional codes. 4 cells are required for QR Codes and Data Matrix.
- Adjust the only one reading code to be within the field of vision. Reading can not be performed correctly if more than one code are on a screen.
- Adjust the field of vision of a camera for the 2-dimensional code to be at least 5 pixels per cell.

**RESET Terminal**

Do not use RESET input immediately after power is turned ON. When using RESET input to synchronize execution timing, wait at least 1 s after turning ON the V530-R150 power supply before turning ON the RESET terminal.

**Terminals**

Do not connect anything to the terminals with no names.



**4 Package Contents**

**Confirming Package Contents**

Check the contents of the package as soon as you receive the V530-R150.

Contact the nearest OMRON representative if any of the following items are missing.

- V530-R150 2-Dimensional Code Reader Controller
- Operation Manual (this manual)

# SECTION 1

## Features


This section gives an overview of the features, applications and basic configurations for the V530-R150 2-Dimensional Code Reader.

1-1	Overview of V530-R150 Application .....
1-2	Functions .....
1-3	Trigger Inputs and Outputs .....

# 1-1 Overview of V530-R150 Application


The following illustrations show configurations and typical applications for the V530-R150.

## Unit Connections and Wiring



Refer to *Section 2 Installation* for detailed descriptions.


## Connections for Peripheral Devices



Refer to *Section 3 Terminal Blocks* and *Section 4 RS-232C* for detailed descriptions.

### Displaying Images


Switch to through image and adjust the focus, camera setting distance, and lighting.



Refer to *Sections 2.4 Camera, 2.5 CCTV Lens, and 2-6 Lighting* for detailed descriptions.


### Setting Reading Conditions

Operate the Console while checking menus on the video monitor.



Refer to *Section 5 Operations and Section 6 Functions and Operations* for detailed descriptions.

Performing Reading



Refer to *Sections 6.3 MON (Monitor) Mode* and *6.4 RUN Mode* for detailed descriptions.


# 1-2 Functions

Easy to check the cause of error when reading is NG judgment using the image analysis mode.  
 → p. 120

Image storage:  
 Up to 24 reading images can be stored in memory. Confirm errors by displaying the stored images.  
 → p. 149

The images in memory are cleared when power is turned OFF.  
 The images in memory can be backed up to a personal computer.  
 → p. 145

The suitable shutter speed can be selected according to the moving rate of the reading codes.  
 → p. 94



## Specifications

Reading code	QR Code (model 1, 2)	Data Matrix (ECC200)
Matrix size	21 x 21 cell to 41 x 41 cell (Version 1 to 6)	10 x 10 cell to 26 x 26 cell
Readable direction	360 degrees (All directions)	
Resolution	Varies according to magnification and features of the lens to be used. (See note.)	
Reading region		
Reading depth		

**Note** Adjust the field of vision to be at least five pixels per cell. Pixel number is measured by *SET/Image Analysis/Measure Length*.  
 → p. 127

## 1-3 Trigger Inputs and Outputs

### Trigger Inputs

- Trigger inputs from terminal blocks: → **p. 25**  
Enter input signals to perform one shot reading, continuous reading and level trigger.
- Trigger inputs from RS-232C: → **p. 46, 52**  
Enter input signals to perform one shot reading and continuous reading.  
Select normal or host link as communications method.
- Trigger inputs from Console:  
Press the TRIG Key to perform one reading.



### Reading Judgment Outputs

- To terminal blocks: → **p. 25**  
Judgment is output to the OK/NG terminal.  
Judgment is output to terminals DO0 to DO3 by using the coincidence judgment function.
- To RS-232C → **p. 46, 52**  
Reading judgment and data are output.  
Select normal or host link as communications method.

# SECTION 2


## Installation

This section describes the different parts of the V530-R150 2-Dimensional Code Reader, and details the connections and other procedures necessary for installation.

- 2-1 Component Names and Functions .....
- 2-2 Connections .....
- 2-3 Power Supply and Ground .....
- 2-3-1 Crimp Terminals and Cables .....
- 2-3-2 Protective Conductor (Earth) Wiring .....
- 2-3-3 Wiring the Power Supply .....
- 2-4 Camera .....
- 2-5 CCTV Lens .....
- 2-6 Lighting .....
- 2-7 Mounting the Controller .....
- 2-7-1 Mounting to DIN Track .....
- 2-7-2 Mounting on a Flat Surface .....

## 2-1 Component Names and Functions

The following diagram shows the terminals, connectors, and indicators on the V530-R150 2-Dimensional Code Reader.




- ① Lit while power is ON.
- ② Lit in RUN mode.
- ③ Lit when an error occurs.
- ④ Connects the V530-R150 to a computer, Programmable Controller, or other external device.
- ⑤ Connects to the Camera.
- ⑥ Wired to the power supply.
- ⑦ Wired to a ground.
- ⑧ Wired to external devices, such as synchronous sensors or inputs from a Programmable Controller.
- ⑨ Wired to external devices, outputs to a Programmable Controller.
- ⑩ Connects to the video monitor.
- ⑪ Connects to the Console.

## 2-2 Connections

Connect the basic component as shown in the following diagram. Details are provided later in this section.

Power Supply → p. 10

\*Components marked with an asterisk are specially designed for the V530-R150. Other products cannot be used.



**Note** Turn OFF the power to the Controller before connecting or disconnecting cables. Connecting or disconnecting cables with power turned ON can damage peripheral devices.


## 2-3 Power Supply and Ground

Wire the power supply and the ground to the top terminal block, and tighten the screws to a torque of between 0.5 and 0.6 N•m. After wiring, check to make sure that the wiring is correct.

**WARNING** Cover the terminal blocks with the Terminal Block Protection Covers. Uncovered terminal blocks can result in electric shock.


### 2-3-1 Crimp Terminals and Cables

The terminal block uses M3 terminal screws. Use appropriate crimp terminals for M3 screws, as shown below.



Applicable wire size: Insulated wire, 1.31 to 1.65 mm<sup>2</sup> (AWG16 to AWG15)

### 2-3-2 Protective Conductor (Earth) Wiring



- Note**
1. Use an appropriate ground. An insufficient ground can affect V530-R150 operation or result in damage to V530-R150 components.
  2. To avoid damage to the equipment, do not share the protective conductor wiring with any other devices nor wire the protective conductor terminal to the girder. Be sure to wire the protective conductor of the equipment independently.
  3. Keep the ground line as short as possible.


### 2-3-3 Wiring the Power Supply

**! WARNING** Use a DC power supply with safe extra low-voltage circuits on the secondary side. Excessively high voltages can result in electric shock.

#### Power supply

Use a power supply with the following specifications. We recommend using OMRON's S82K-01524 Power Supply.

Output current	0.6 A min.
Power supply voltage	24 VDC+10%, -15%



- Note**
1. Wire the Power Supply Unit independently of other devices. In particular, keep the power supply wired separately from inductive loads.
  2. Keep the power supply cable as short as possible.
  3. If UL recognition is required, use a UL class II power supply.


## 2-4 Camera

The camera is designed for the V530-R150.

### Mounting the Camera

The specified camera distance is only an approximation. Mount the Camera so that it can be adjusted within a range containing the specified distance from the reading object.

- Camera





## 2-5 CCTV Lens

When using a F150-S1 Camera, refer to the following graph to select the appropriate Lens end Extension Tube. The lens required will differ depending on the size of the reading object and the distance from the Camera. Adjust the field of vision of the Camera so that a 2-dimensional code is at least 5 pixels per cell.

### Optical Chart


The X axis of the graph shows field of vision L (mm), and the Y axis shows the camera distance A (mm). The curves on the graph indicate different lenses, and the "t" values indicates the lengths of the Extension Tubes. The values in the following chart are approximations, and the Camera must be adjusted after it is mounted.






**Lens**

	Focal length	Brightness	Max. outer diameter	Total length	Filter size
3Z4S-LE C418DX	4.8 mm	F1.8	40.5 mm dia.	35.5 mm	---
3Z4S-LE B618CX-2	6.5 mm	F1.8	48 mm dia.	42 mm	
3Z4S-LE C815B	8.5 mm	F1.5	42 mm dia.	40 mm	M40.5 × P0.5
3Z4S-LE B1214D-2	12.5 mm	F1.4	42 mm dia.	50 mm	
3Z4S-LE C1614A	16.0 mm	F1.4	30 mm dia.	33 mm	M27 × P0.5
3Z4S-LE B2514D	25.0 mm	F1.4	30 mm dia.	37.3 mm	
3Z4S-LE B5014A	50.0 mm	F1.4	48 mm dia.	48 mm	M46 × P0.75
3Z4S-LE B7514C	75.0 mm	F1.4	62 mm dia.	79 mm	M58 × P0.75




**Extension Tubes**

One or more Extension Tubes are inserted between the lens and the Camera to focus the Camera image. Use a combination of one or more of the six sizes of tube to achieve the required length.



Model	Max. outer diameter	Length
3Z4S-LE EX-C6	31 mm dia.	Set of 6 tubes 0.5 mm, 1 mm, 5 mm, 10 mm, 20 mm, and 40 mm



- Note**
1. Do not use the 0.5-mm and 1.0-mm Extension Tubes attached to each other. Since these Extension Tubes are placed over the threaded section of the Lens or other Extension Tubes the connection may loosen when more than one 0.5-mm or 1.0-mm Extension Tube are used together.
  2. Reinforcement may be required for a combination of Extension Tubes exceeding 30 mm if the Camera is subject to vibration.

## 2-6 Lighting


A stable image must be obtained to ensure accurate inspection. Use appropriate lighting for the application and the reading object.

### Lighting Methods

#### Back Lighting

A stable, high-contrast image can be obtained using back lighting.

Applications: Transparent objects such as LCD glass




#### Reflected Lighting

##### Ring Lights

Light is shone uniformly on the reading object. The difference in reflection factors of the background and the marking enable stable detection.


Applications: Paper labels and corrugated cardboard



**Oblique Lighting**

Detection is made by distinguishing regular and diffuse reflected light.


Applications: PCBs and electronic parts



**Coaxial Lighting**

A stable image with few shadows can be obtained of a reading object with an uneven surface by detecting only regular reflected light.

Applications: Mirror-like objects such as wafers




## 2-7 Mounting the Controller

The V530-R150 2-Dimensional Code Reader can be mounted to DIN Track or a flat surface.

### 2-7-1 Mounting to DIN Track

The 2-Dimensional Code Reader can be easily mounted to or removed from 35-mm DIN Track.


The following DIN tracks are available from OMRON.  
PFP-100N (1 m)  
PFP-50N (50 cm)  
PFP-100N2 (1 m)



PEP-M End Plate (OMRON)


### Mounting the Controller

Hook the Controller into the DIN Track as shown in the diagram and then press in at the bottom until the Controller locks into place.




Removing the Controller

Use a screwdriver to pull the hook down and then pull out the Controller from the bottom.



2-7-2 Mounting on a Flat Surface



# SECTION 3

## Terminal Blocks

This section describes the specifications, procedures, inputs and outputs used when operating the V530-R150 2-Dimensional Code Reader via terminal blocks.


- 3-1 Specifications . . . . .
- 3-1-1 Crimp Terminals and Cables . . . . .
- 3-1-2 Specifications . . . . .
- 3-1-3 Terminals . . . . .
- 3-2 Trigger Input and Output Format . . . . .
- 3-2-1 Trigger Input . . . . .
- 3-2-2 Output Format . . . . .
- 3-3 Timing Chart . . . . .
- 3-3-1 One Shot Mode . . . . .
- 3-3-2 Continuous Mode . . . . .
- 3-3-3 Reading Level Trigger  
        (when trigger mode is "Level Trigger") . . . . .
- 3-4 System Examination . . . . .

## 3-1 Specifications

### 3-1-1 Crimp Terminals and Cables

The terminal block uses M3 terminal screws. Use appropriate crimp terminals for M3 screws, as shown below. Tighten the screws to a torque of between 0.5 and 0.6 N·m. After wiring, check to make sure that the wiring is correct.

**! WARNING** Cover the terminal blocks with the Terminal Block Protection Covers. Uncovered terminal blocks can result in electric shock.



Applicable wire size: Insulated wire, 1.31 to 1.65 mm<sup>2</sup> (AWG16 to AWG15)

### 3-1-2 Specifications

**! WARNING** Use a DC power supply with safe extra low-voltage circuits on the secondary side. Excessively high voltage can result in electric shock.

#### Input Specifications


Item	V530-R150E (NPN model)	V530-R150EP (PNP model)
Input voltage	12 to 24 VDC ±10%	
ON current	3 to 15 mA	
ON voltage	8.8 V max.	
OFF current	0.1 mA max.	
OFF voltage	4.5 V min.	
ON delay	RESET input: 10 ms max. Others: 0.5 ms max.	
OFF delay	RESET input: 15 ms max. Others: 0.7 ms max.	
Internal circuits		

Output Specifications

Item	V530-R150E (NPN model)	V530-R150EP (PNP model)
Output voltage	12 to 24 VDC $\pm 10\%$	
Load current	45 mA max.	
ON residual voltage	2 V max.	
OFF leakage current	0.1 mA max.	
Internal circuits		

**Note** If UL recognition is required, use a UL class II power supply.

3-1-3 Terminals



There are 3 kinds of COM OUT (\*1 to \*3) for each output terminal. Connect with reference to the following table.

**A**

Top		Bottom	
+	Power supply	NC	Not connected
-		$\perp$	Appropriate ground
RUN	Control output	ERR	Error output
BUSY		GATE	Control output
OK/NG	Judgment output	NC	Not connected
COM OUT (*1)	For RUN, ERR, BUSY, GATE, and OK/NG	RESET	Restart
DSA	Prohibited to use	TRIG A	Trigger input (One shot mode)
COM IN		TRIG B	Trigger input (Continuous or Level Trigger mode)

**B**

Top		Bottom	
DO 1	Coincidence output	DO 0	Coincidence output
DO 3		DO 2	
DO 5	Prohibited to use	DO 4	Prohibited to use
DO 7		DO 6	
NC	Not connected	COM OUT (*2)	For DO 0 to DO7
DO 9	Prohibited to use	DO 8	Prohibited to use
DO 11		DO 10	
DO 13		DO 12	
DO 15		DO 14	
		COM OUT (*3)	For DO 8 to DO15

- Note**
1. Do not reverse the connections of the signal terminals and COM terminals.
  2. Do not use RESET input immediately after power is turned ON.  
When using RESET input to synchronize execution timing, wait at least 1 s after turning ON the V530-R150 power supply before turning ON the RESET terminal.

## 3-2 Trigger Input and Output Format

### 3-2-1 Trigger Input

Reading is performed by inputting a signal to the TRIG A or B terminals when in MON (monitor) or RUN mode.

#### TRIG A Terminal (One shot mode)

One reading is performed on the rising edge (OFF to ON) of TRIG A signal.

Correct Reading: Reading ends, then reading judgment is output.

Incorrect Reading: Reading continues to be performed for the number of retries specified in the setting conditions.

How to set the number of retries. → **p. 97, 113**

As the TRIG A signal is synchronous with the shutter input of the Camera, an accurate image of the moving object can be obtained.

#### TRIG B Terminal (Continuous mode / Level trigger mode)

Changed by setting of communications specifications.

→ **p. 143**

Trigger Mode	Detail
Continuous mode (Default setting)	Performs continuous reading while the TRIG B terminal is ON.
Level trigger mode	Repeats reading while the TRIG B terminal is ON until reading judgement is OK (readable).

### 3-2-2 Output Format

Signals are output in RUN mode but not in MON (monitor) mode.

#### OK/NG Terminal

Output OK/NG judgment.

Judgment	Detail
OK	OK when 2-dimensional codes are read successfully. The reading data will be output to RS-232C.
NG	NG when 2-dimensional codes are not read successfully. The error code will be output to RS-232C.  NG when coincidence judgment is set to ON and the reading data is not coincident with the registered data 0 to 3. The reading data will be output to RS-232C.

OK: ON or NG: ON (i.e.: whether output turns ON for an OK judgment or an NG judgment) can be selected in the communications

specifications settings.

The default setting is NG: ON. → p. 143

### **DO0 to DO3 Terminals**

While the coincidence judgment function is ON, the signals are as follows:

How to set coincidence judgment function → p. 102, 118

Coincident with registered data 0: DO0 terminal turns ON.

Coincident with registered data 1: DO1 terminal turns ON.


Coincident with registered data 2: DO2 terminal turns ON.

Coincident with registered data 3: DO3 terminal turns ON.

**Note** The initial status of the output terminals is OFF. The terminals, however, may turn ON for approximately 0.5 s when the power is turned ON. Be sure to allow for this when connecting to an external device.

### 3-3 Timing Chart

#### 3-3-1 One Shot Mode



**Note** The output time to RS-232C changes depending on the data volume or baud rate.


## Output Terminals

Terminal	Function
RUN	Turns ON during RUN mode.
BUSY	Shows that the V530-R150 is reading an image, changing settings, etc. Do not input the next command while the BUSY signal is ON. Otherwise, commands may not be properly executed.
OK/NG	Outputs the judgment under the set reading conditions. (Can be set to turn ON for either OK or NG judgment.)
GATE	Used to control the timing with which the reading judgment is read at the external device. The duration for which the GATE terminal is turned ON can be set as required for the external device to correctly read the reading judgment. Make the output cycle shorter than the duration of the reading (TRIG A input). If the cycle is longer, the output timing falls behind as readings are repeated. Gate ON delay, Gate ON time and Output period are set under the set communications conditions. → p. 143

## Input Terminals

Terminal	Function
TRIG A	Inputs a reading trigger from a photoelectric sensor or other external device. One reading is taken on the rising edge of the TRIG A signal. Turn ON for at least 0.5ms. The duration of TRIG A signal input depends on reading time. While reading is being performed, BUSY terminal turns ON and does not accept input signals. Refer to 3-4 System Examination for the standard reading time.

### 3-3-2 Continuous Mode



**Note** The output time to RS-232C changes according to the data volume and baud rate.

**Output Terminals**


Terminal	Function
RUN	Turns ON during RUN mode.
BUSY	Shows that the V530-R150 is reading an image, changing settings, etc. Do not input the next command while the BUSY signal is ON. Otherwise, commands may not be properly executed.
OK/NG	Outputs the judgment under the set reading conditions. (Can be set to turn ON for either OK or NG judgment.)
GATE	Used to control the timing with which the reading judgment is read at the external device. The duration for which the GATE terminal is turned ON can be set as required for the external device to correctly read the reading judgment. Make the output cycle shorter than the duration of the reading. If the cycle is longer, the output timing falls behind as readings are repeated. Gate ON delay, Gate ON time and Output period are set under the set communications conditions. → p. 143

**Input Terminals**

Terminal	Function
TRIG B	Continuous reading is performed when TRIG B signal is turned ON.

### 3-3-3 Reading Level Trigger (when trigger mode is “Level Trigger”)

OK judgment (Readable)



**Note** The output time to RS-232C changes according to the data volume and baud rate.


#### Output Terminals

The same as continuous mode.

#### Input Terminals

Terminal	Function
TRIG B	Continuous reading is performed while TRIG B signal is turned ON until OK (readable) reading judgment is output.


OK judgment obtained after repeated reading:



**Note** The output time to RS-232C will vary according to the data volume and baud rate.

**NG judgment after repeated reading:**

NG is output when TRIG B is turned OFF.



**Note** The output time to RS-232C will vary according to the data volume and baud rate.

## 3-4 System Examination

### Processing Time Calculation

Processing time (reading time) is calculated as follows:

$$\begin{aligned}
 \text{Processing time} &= \boxed{\text{Shutter time of camera}} + \boxed{\text{Delay of loading image (see note)}} + \boxed{\text{Loading image time (33.3 ms fixed)}} \\
 &+ \boxed{\text{Decode time}} + \boxed{\text{Display time}}
 \end{aligned}$$

**Note** A delay will occur before starting to load video monitor images if through images are displayed. A delay may also occur depending on the trigger input method.

### Reading Moving Objects

Please note the following to prevent delay when loading images.

- Use the TRIG A signal for timing input.  
As the TRIG A signal is synchronous with the shutter input of the Camera, an accurate image of the moving object can be obtained.
- Set the image to be displayed on the video monitor to "Freeze".  
When through images are displayed, a delay of 33.3 ms max. occurs before loading images after the TRIG A signal input.

### Line Speed

If the object moves while the image is being loaded after the shutter is released, the image will be blurred. Set the line speed according to the shutter speed (using V530-R150 menu), the cell size of objects, and the field of vision of the Camera.

### Tact Time

A certain interval is necessary between reading objects during which the next trigger signal is not input. This interval (time) is called "Tact Time".

(e.g.) Processing time for reading: 500 ms; Line speed: 30 m/min

$$\frac{30}{60} \times 0.5 = 0.25$$

The distance moved in 500 ms is 0.25 m. Therefore, an interval allowing 0.25 m min. of movement is necessary.

### Number of Retries

If reading is NG, reading continues to be performed for the number of retries specified by the setting conditions. When reading moving objects, reading may continue after the object has left the field of vision. Set the number of retries so that reading is performed while the object is still within the field of vision, or set to 0.

**Continuous Reading**

Regardless of the displayed image (through/freeze), a 33.3 ms max. delay occurs before loading the image after the TRIG B signal is input.

**Standard Processing Time (values for OMRON's standard codes)****QR Code**

Matrix size	Processing time
21 X 21 (Version 1)	160 ms
29 X 29 (Version 3)	200 ms
41 X 41 (Version 6)	260 ms

**Data Matrix**

Matrix size	Processing time
10 X 10	180 ms
14 X 14	190 ms
26 X 26	250 ms

**Note** The data here are standard values. When installing, calculate the processing time according to the actual specifications and confirm the value in the actual operating environment. The processing time is displayed in the upper-right corner of the screen when reading is performed in MON (monitor) or RUN mode.

# SECTION 4

## RS-232C


This section describes the specifications, procedures, inputs and outputs used when operating the V530-R150 2-Dimensional Code Reader via RS-232C.

- 4-1 Specifications . . . . .
- 4-1-1 Connector . . . . .
- 4-1-2 Wiring . . . . .
- 4-1-3 Connection . . . . .
- 4-2 Communication Settings . . . . .
- 4-2-1 Normal Communications Mode . . . . .
- 4-2-2 Host Link . . . . .
- 4-3 Trigger Inputs and Output Format . . . . .
- 4-3-1 Normal . . . . .
- 4-3-2 Communications Mode: Host Link . . . . .
- 4-4 FCS Calculation . . . . .
- 4-5 Connection Examples . . . . .
- 4-5-1 Connection Examples for Programmable Controller (Normal) . . . . .
- 4-5-2 Connection Examples for Programmable Controller (Host Link) . . . . .
- 4-5-3 Connection Examples for Personal Computers (Normal) . . . . .

## 4-1 Specifications

### 4-1-1 Connector

The V530-R150 uses 9-pin D-SUB female connectors. The pin numbers and names are shown below.



#### Recommended OMRON Connector


Model	Model No.
Plug	XM2A-0901
Hood	XM2S-0911

Pin	Signal	Name
1	FG (GND)	Frame ground
2	SD (TXD)	Send Data
3	RD (RXD)	Receive Data
4	RS (RTS)	Request to Send
5	CS (CTS)	Clear to Send
6	NC	Not connected
7	NC	Not connected
8	NC	Not connected
9	SG (GND)	Signal ground


## 4-1-2 Wiring

Only use a shielded RS-232C cable.

### Standard Connections




### Connections for RS/CS Control



**Note** Pin numbers will depend on the external device being connected.  
Refer to the manual for the external device.

### 4-1-3 Connection

Align the connector with the socket and press the connector straight into place. Tighten the two screws on the edges of the connector.




- Note**
1. Always turn OFF the power supply before connecting or disconnecting cables. Peripheral devices can be damaged if connected or disconnected with the power supply turned ON.
  2. Always tighten the connector screws.

## 4-2 Communication Settings

### 4-2-1 Normal Communications Mode

If the Normal communications mode is selected, data can be output in normal format to an external device via the RS-232C port. Communications method setting menu → p. 140


#### I/O via the RS-232C Port



A timeout error occurs if there is no response from the host computer within the set time when RS/CS or Xon/off is selected for flow control. An ERR (error) message appears on the screen, and the error terminal turns ON.

Program example → p. 63

**TRIG A Signal as Reading Trigger**



A timeout error occurs if there is no response from the host computer within the set time when RS/CS or Xon/off is selected for flow control. An error message appears on the screen, and the ERR (error) terminal turns ON.

Program example → **p. 58**

**4-2-2 Host Link**


Select Host Link for the communications mode to communicate in Host Link format with a Programmable Controller or other host device via the RS-232C port.

Communications method setting menu → **p. 140**

**I/O via the RS-232C Port**

Commands for the V530-R150 are written to the Read Area in the Programmable Controller.


The V530-R150 automatically reads these commands, executes them, and writes any judgments to the Write Area.



A timeout error occurs if there is no response within 5 s. An error message appears on the screen and the ERR (error) terminal turns ON.

TRIG A Signal as Reading Trigger


Set the Read Area to "None."



A timeout error occurs if there is no response within 5 s. An error message appears on the screen and the ERR (error) terminal turns ON.

Using TXD Instructions

Commands are sent from the Programmable Controller to the V530-R150 using TXD instructions in the Programmable Controller's ladder program instead of the Read Area. If TXD instructions are to be used to send commands, set the Read Area to "None."



Program example → p. 61

## 4-3 Trigger Inputs and Output Format

### 4-3-1 Normal

**Command**

Connection	Function	Command
1:1	One shot reading	@GL
	Start continuous reading	@GC
	Stop continuous reading	@SC
	Request to resend reading data	@RS
	Read the scene number currently displayed	@SN
	Switch the scene	@SN_Scene No.
1:N (Multi drop)	One shot reading	@GL_unit No.
	Polling	@RD_Unit No.
	Read the scene number currently displayed	@MS_Unit No.
	Switch the scene	@MS_Unit No._ Scene No.

**Note** “\_” in the above commands means space.

**Error Code**

The following error codes are output according to the cause of error when the reading is NG. (FP = Finder Pattern.) Refer to 9-2 *Error Codes and Remedies* for details.

**QR Code**

Error Code	Description
E000	No FP
E001	Missing 2 FPs
E002	Missing 1 FP
E003	3 FPs in wrong position
E004	More than 4 FPs
E010	Decode error
E011	
E012	
E013	
E020	
E030	


**Data Code**

Error Code	Description
E100	No candidate for FP
E110	No FP
E111	Error 1 FP
E112	FP in wrong position
E120	Decode error
E121	
E122	
E123	
E150	

- The items in dotted boxes can be selected to be added or not in the communication setting menu. → p. 140



- Insert one space in the blank box.



**One Shot Reading (@GL)**

**1:1 Connection**


Reading ends and the judgments are output when the reading is correctly performed. When the reading is not correctly performed reading continues to be performed for the number of re-tries specified in the setting conditions.

**Send**




**Receive**

Correct reading:




Incorrect reading:

Reading continues to be performed for the number of retries specified in the setting conditions. An error code is output when an error occurs.




When Reading Accuracy is ON:



The judgment (reading accuracy) of 10 readings is displayed. When the reading accuracy is 0%, “?” is displayed for reading data.

When Coincidence Judgment is ON:




Coincident with registered data 0 : 00  
 Coincident with registered data 1 : 01  
 Coincident with registered data 2 : 02  
 Coincident with registered data 3 : 03  
 Not coincident with registered data 0 to 3: NG

**Continuous Reading (@GC, @SC) 1:1 Connection**

Performs continuous reading until the stop command (@SC) is sent.


Send

Starts reading.




Receive


Correct reading:



Incorrect reading:




When Coincidence Judgment is ON:



- └─ Coincident with registered data 0 : 00
- └─ Coincident with registered data 1 : 01
- └─ Coincident with registered data 2 : 02
- └─ Coincident with registered data 3 : 03
- └─ Not coincident with registered data 0 to 3: NG

**Send**

Stops continuous reading.



**Request to Resend Scene Data (@RS) 1:1 Connection**

Resends the last reading data.  
 If the command is input while reading is performed, the data will be resent after the reading is completed.

**Send**



**Receive**

Last reading data


**Read the Scene Number Currently Displayed (@SN) 1:1 Connection**

The displayed scene number (0 to 9) is output.

**Send**



**Receive**



**Switch the Scene (@SN Scene No.) 1:1 Connection**

Switches the scene number to be displayed.

**Send**




Specify 0 to 9 for the scene no.

**Receive**

Correctly switched:



Incorrectly switched:



**One Shot Reading (@GL Unit No., @RD Unit No.) 1:N Connection**


Reading ends if the reading is performed correctly. If the reading is not performed correctly, reading continues to be performed for the number of retries specified in the setting conditions. Reading data is not output until polling commands are given.

**Send**




**Receive**


Correct reading:



Incorrect reading:




When Reading Accuracy is ON:



The judgment (reading accuracy) of 10 readings is displayed. When the reading accuracy is 0%, “?” is displayed for reading data.

When coincidence judgment is ON:



Coincident with registered data 0: 00  
 Coincident with registered data 1: 01  
 Coincident with registered data 2: 02  
 Coincident with registered data 3: 03  
 Not coincident with registered data 0 to 3: NG

**Send**

Polling



**Read the Scene Number Currently Displayed (@MS Unit No.)  
 1:N Connection**


The displayed scene number (0 to 9) is output.

**Send**



**Receive**

Data is output from the V530-R150 without polling commands.



**Switch the Scene (@MS Unit No. Scene No.) 1:N Connection**


Switches the scene number to be displayed.

**Send**




**Receive**

Data is output from the V530-R150 without polling commands.  
 Correctly switched:



Incorrectly switched:



**4-3-2 Communications Mode: Host Link**

**Command Table**

Command Code	Function
10	One shot reading
11	Start continuous reading
12	Stop continuous reading
20	Switch to a specified scene number
21	Increase the displayed scene number by one
22	Decrease the current scene number by one
23	Read the scene number currently displayed

**Error Code Table**

Following error codes are output according to the cause of errors when NG reading judgment is output. (FP = Finder Pattern)  
 Refer to 9-2 Error Codes and Remedies for details.

**QR Code**

Error Code	Description
E000	No FP
E001	Missing 2 FPs
E002	Missing 1 FP
E003	3 FPs in wrong position
E004	More than 4 FPs
E010	Decode error
E011	
E012	
E013	
E020	
E030	

**DataMatrix**

Error Code	Description
E100	No candidate for FP
E110	No FP
E111	Error 1 FP
E112	FP in wrong position
E120	Decode error
E121	
E122	
E123	
E150	

**One Shot Reading (10)**

**1:1 Connection**

Reading ends and the judgments are output when the reading is correctly performed. When the reading is not correctly performed, reading continues to be performed for the number of retries specified in the setting conditions. The reading judgments are output to a write word.

**Read**

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 0 1	0 0 0 0	Command code

**Continuous Reading (11, 12)**

**1:1 Connection**

Starts continuous reading

Continuous reading is performed.

The reading judgment is output to a write word.

**Read**

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 0 1	0 0 0 1	Command code

Stops continuous reading.

**Read**

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 0 1	0 0 1 0	Command code

**Reading Judgment**

**Write**

Begin write word	Bit			
	15 to 12	11 to 8	7 to 4	3 to 0
+0	Write flag	0 0 0 0	0 0 0 0	0 0 0 0
+1	Reading data 1st byte		Reading data 2nd byte	
+2	Reading data 3rd byte		Reading data 4th byte	
to	to		to	
+27	Reading data 53th byte		Reading data 54th byte	
+28	Reading data 55th byte		Reading data 56th byte	

- Reading data is stored with ASCII codes.
- Write flag switches between [0 0 0 0] ↔ [1 1 1 1] each time data is output. Monitor the flag to see whether reading judgment has been written.
- The data capacity (max.) of codes is as follows.  
Letters and numbers: 56 letters  
The reading data after 56th letter are ignored.
- When reading is NG, error codes are output to word +1.
- When the byte of reading data is an odd number, a space (ASCII code 20) is inserted in 0 to 7th byte.

**Switch the Scene (20)**

**1:1 Connection**

Specify the scene number to be switched.

**Read**

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 1 0	0 0 0 0	Command code
+1	----	----	----	Scene No.	Scene number (0 to 9)

Either 0 or 1 can be set for “-.”

**Switch the Scene Number +1 (21) 1:1 Connection**

Increases the scene number by one.  
When the current scene number is 9, the scene number will switch to 0.

Read

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 1 0	0 0 0 1	Command code

**Switch the Scene Number -1 (22) 1:1 Connection**

Decreases the scene number by one.  
When the current scene number is 0, the scene number will switch to 9.

Read

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 1 0	0 0 1 0	Command code

**Read the Scene Number Currently Displayed (23) 1:1 Connection**

Read

Begin read word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	0 0 0 0	0 0 0 0	0 0 1 0	0 0 1 1	Command code

Write


Begin write word	Bit				Setting
	15 to 12	11 to 8	7 to 4	3 to 0	
+0	Write flag	0 0 0 0	0 0 0 0	0 0 0 0	Write flag
+1	0 0 0 0	0 0 0 0	0 0 0 0	Scene No.	Scene number (0 to 9)

Write flag switches between [0 0 0 0] ↔ [1 1 1 1] each time data is output. Monitor the flag to confirm whether reading judgment has been written.

## 4-4 FCS Calculation

FCS (Frame Check Sequence) can be attached to output data to improve communications. (For normal communications only). FCS is the result of taking the XOR for each byte between header and footer (8 bits) and converting to 2-character ASCII codes. Each time data is received, the host link calculates the FCS and checks it against the FCS attached to sending data so that sending data can be checked for errors. Refer to *Appendix B FCS Check Program Examples (BASIC)*. → p. 181

(e.g.) Reading data: ABCDEFG  
 The sending data is as shown below.



Calculation


	ASCII code		
A	41	0100	0001
		XOR	
B	42	0100	0010
		XOR	
C	43	0100	0011
		XOR	
D	44	0100	0100
		XOR	
E	45	0100	0101
		XOR	
F	46	0100	0110
		XOR	
G	47	0100	0111
<hr/>			
Result		0100	0000
		↓	↓
		4	0

Converted into hexadecimal and used as ASCII codes.


## 4-5 Connection Examples

### 4-5-1 Connection Examples for Programmable Controller (Normal)

#### System Configuration



#### Cable Wiring



**Communication Settings**

- V530-R150 → p. 140

Item	Setting
Baud rate	19200 bps
Data length	8 bit
Parity bits	EVEN
Stop bits	2 bit
Header	None
Footer	CR
Mode	Normal


- Programmable Controller:  
 Turn OFF the DIP switch of CQM1.  
 Set DM6645 to [1001], DM6646 to [0904], DM6648 to [1000]  
 and DM6649 to [0D00].  
 Match communication settings with the V530-R150. Refer to  
 the operation manual for CQM1 for the ways to change the set-  
 ting.

**Program Examples**

This is an example of a program in which a Programmable Controller (CQM1) receives the data which is read at a V530-R150.


- 1 Set the reading conditions of the V530-R150 and set the reading mode to RUN mode.
- 2 The synchronous sensor or trigger input of the console sends the reading trigger to the V530-R150.  
 → The V530-R150 reads the code and outputs data.

- 3 The data received from the CQM1 is saved in order from the highest digit in DM0200 from the first bit.




### 4-5-2 Connection Examples for Programmable Controller (Host Link)

#### System Configuration



**Cable Wiring**



(\*) Pin numbers will depend on the CPU unit or Host Link Unit being connected. Refer to the manual for the Programmable Controller being connected.

**Communication Settings**

- V530-R150 → p. 140

Item		Setting
Communication setting	Baud rate	The same settings as those of the Programmable Controller.
	Data length	
	Parity bits	
	Stop bits	
	Mode	
Host Link setting	Read area	None
	Begin read word	---
	Write area	DM
	Begin write word	0110

- Programmable Controller


Item	Setting
Communications mode	SYSWAY (Host Link)
1 : 1 / 1 : N	1 : N
Unit No.	00
Baud rate	Match the settings with a V530-R150
Data length	
Parity bits	
Stop bits	

Set DM0100 to [0010] in advance.

Program Examples


A command (reading trigger) is sent to the V530-R150 and the data received at the V530-R150 is written to the specified words of the Programmable Controller.

- 1 Set the reading conditions of the V530-R150 and set the reading mode to RUN mode.
- 2 Set the reading start command [0010] to DM0100.
- 3 The Programmable Controller sends the reading start command.  
→ The V530-R150 reads codes and writes to DM0111.
- 4 The Programmable Controller checks if the data has been written by checking the writing flag [DM0110].




### 4-5-3 Connection Examples for Personal Computers (Normal)

#### System Configuration



#### Cable Wiring



(\*) Pin numbers will depend on the type of personal computer connected. Refer to the manual of the personal computer.

#### Communication Settings

Match the communication settings (baud rate, data length, parity bits, and stop bits) of the personal computer and V530-R150. Set the communications mode of the V530-R150 to **Normal**.

→ p. 140, 141

**Program Example**

```
100 CLOSE #1
110 OPEN "COM:E73NN" AS #1 (OPEN communications port)
120 PRINT #1,"@GL"+CHR(&H0D) (Send single reading command)
130 INPUT #1,RESDATA$ (Load data; footer code:CR)
140 PRINT "READ DATA=";RESDATA$ (Display reading data)
150 GOTO 120 (Repeat)
160 END
```

# SECTION 5

## Operations

This section gives an overview of menu operations for the V530-R150 2-Dimensional Code Reader and explains the procedures required to perform basic operations.


For more details of operations on the V530-R150, refer to *Section 6 Functions and Operations*.

5-1	Menu Operations .....
5-2	Menu Tree .....
5-3	STEP 1 Starting .....
5-4	STEP 2 Setting Reading Conditions .....
5-5	STEP 3 Checking Reading .....
5-6	STEP 4 Starting Code Reading .....
5-7	STEP 5 Quitting .....

# 5-1 Menu Operations


## Console

The Console is used to perform menu operations. Be sure to familiarize yourself with Console operations before actually using the menus.



Key	Function
ESC	Interrupts processing and returns to the previous menu display.
TRIG	Starts code reading (One push → One reading)
ENT	Executes a function or sets a value.
/	Used to move the cursor up and down to select items. Also used to set values. The Up Key increases a value by 1 and the Down Key decreases a value by 1. Continue pressing the Up or Down Key to quickly increase or decrease a value.
□/	Used to move the cursor left or right to select items.
SHIFT	Must be pressed in combination with another key to have any affect. Specific functions are assigned to Shift + another key for specific screens.

Screen Displays




## Mode (\*1)


<b>Mode</b>	<b>Description</b>
SET (Set)	Used to set reading conditions.
MON (Monitor)	Used to confirm the reading can be properly performed under the set conditions. Judgments are displayed on the video monitor and are not output to external devices.
RUN (Run)	Used to read codes. The judgment is output to external devices or RS-232C via the terminal blocks.
SYS (System)	Used to set system conditions such as communications specifications.
SAVE (Save)	Used to save setting data to flash memory. Be sure to save and turn OFF power to the V530-R150 after changing the settings.

# 5-2 Menu Tree

## For QR Code Reading



For DataMatrix Code Reading




## 5-3 STEP 1 Starting

### Procedure

- 1 Be sure that the basic V530-R150 components have been connected correctly. → p. 9
- 2 Turn ON the power supply on the monitor.
- 3 Turn ON the power supply on the V530-R150.


A startup message appears followed by a processing message. After a short pause, the initial screen appears. The following screen appears the first time power is turned ON.



**Note** Never input the reset signal or turn OFF the power when startup messages are displayed. Data may be lost, and the V530-R150 may not operate properly the next time it is started.

- 4 Be sure that the 2-dimensional code is correctly displayed within the field of vision on the monitor.

The through image is displayed by pressing the SHIFT + Down Keys. If not displayed correctly, adjust the focus, camera setting distance and lighting. → p. 13, 16



**Startup Mode**

Use the startup mode in order to make daily operation more efficient. → p. 150

## 5-4 STEP 2 Setting Reading Conditions


The default setting is for MON (monitor) mode to be displayed when the power is first turned ON.

**Note** This section only describes the necessary functions for basic operations. Other functions are described in *Section 6 Functions and Operations*.

### Procedure


- 1 Move the Right Key to MON (monitor) and press the ENT Key.

The mode selections are displayed.




- 2 Move to SET using the Up Key and press the ENT Key.

The following screen is displayed. The screen is in setting mode.



3 Register menus in 0 to 3.

Press the ENT Key to display the selection of menus. When changing a registered menu, press the SHIFT+ESC Keys to display the selection of menus.




### QR Code Reading

Set the following four items.

- Shutter Speed
- Symbol Color
- Right & Left Reverse ON/OFF
- Gray Edge Value

4 Register the menu as shown in the figure.



5 Select **0.Image Adjust -QR**.


6 Select **Shutter Speed**.




7 Select the shutter speed according to the movement of the reading object.

Press the ENT Key to set the shutter speed. The display will return to the window shown in step 6.


Press the ESC Key once to go back to the window shown in step 4.




8 Select *Read QRCode*.



9 Select *Reading Settings*.




10 Select the color of symbol.



Black: Black symbol printed on white base.

White: White symbol printed on black base.



11 Select if Right & Left Reverse is necessary or not.

ON: Necessary


For reading an image after reflection, or through the back of a transparent material such as glass.

OFF: Unnecessary

For normal reading (from the front of the object).


12 Select **Register** before leaving this screen.

13 Select **Function Settings**.



14 Set **Judge Gray Value** to ON.

Turn ON this function and enter MON (monitor) or RUN mode. When the TRIG Key is pressed and one reading is performed, the ideal gray edge value is automatically set to **Reading Settings/Judge Gray Value**. Turn OFF the function after setting.




15 Select **Register** before leaving the screen.

### Data Matrix Reading

Set the following five items.

- Shutter Speed
- Symbol Color
- Right & Left Reverse ON/OFF
- Matrix Size
- L Length

4 Register the menu as shown below.



5 Select **0. Image Adjust-DM**.

6 Select **Shutter Speed**.




7 Select the shutter speed according to the movement of the reading object.

Press the ENT Key to set the shutter speed. The display will return to the window shown in step 6.

Press the ESC Key once to go back to the window shown in step 4.


8 Select **1. Read DataMatrix**.




9 Select **Reading Settings**.



10 Select the color of symbol.



Black: Black symbol printed on white base. White: White symbol printed on black base.



11 Select if Right & Left Reverse is necessary or not.

ON: Necessary

For reading an image after reflection, or through the back of a transparent material such as glass.

OFF: Unnecessary

For normal reading (from the front of the object).

12 Select the matrix size of codes.

Range: 10 x 10 to 26 x 26

13 Select **Register** before leaving this screen.

14 Select **Function Settings**.



15 Set **Measure L Length** to ON.

Turn ON this function and enter MON (monitor) or RUN mode. When the TRIG Key is pressed and one reading is performed, the L length is measured and the result will automatically be used in the **Reading Settings/Length of Finder** setting. Turn OFF the function after setting.

Cell Verify	: OFF ▼
Judge Coincidence	: OFF ▼
Data History	: OFF ▼
Reading Accuracy	: OFF ▼
Measure L Length	: OFF ▼
<b>Register</b>	Cancel


16 Select **Register** before leaving the screen.

## 5-5 STEP 3 Checking Reading

Confirm whether reading is performed correctly under the setting conditions. The reading is performed in MON (monitor) mode. Reading judgment is not output to terminal blocks or RS-232C but displayed on the monitor.

### Procedure

- 1 Press the ESC Key from the basic screen of setting mode to enter MON (monitor) mode.



- 2 Press the TRIG Key on the Console.

One reading is performed. A trigger can be input via terminal blocks or RS-232C. Reading judgement is not output to the terminal blocks or RS-232C but displayed on the monitor.



3 Go back to setting mode and turn OFF *Read QRCode/Function Settings/Judge Gray Value* or *Read DataMatrix/Function Settings/Measure L Length*.

**If Reading Not Performed**


- Return to setting mode and set the conditions correctly. Adjust the lighting and focus.
- Adjust 2-dimensional codes to be at least 5 pixels per cell.
- Refer to the error codes on the screen and *9-2 Error Codes and Remedies*.

## 5-6 STEP 4 Starting Code Reading

Enter RUN mode to perform readings. The reading judgment is output to external devices through terminal blocks or RS-232C.

### Procedure

- 1 Move the cursor to **MON** (monitor) and press the ENT Key. The mode selections are displayed.



- 2 Select **RUN**.

The following screen is displayed.



- 3 Input reading trigger.  
Reading is performed.




## 5-7 STEP 5 Quitting

**Note** Be sure to save the revised setting data to flash memory before turning OFF.


As the V530-R150 loads data from flash memory at startup, any new data be will lost if it is not saved to flash memory. Also, images in RAM are cleared when power is turned OFF. It is recommended that images are backed up on a computer as they can not be saved to flash memory. → p. 145

### Procedure

- 1 Basic screen is displayed.




- 2 Select **MON** (monitor) and press the ENT Key.



- 3 Select **SAVE**.
- 4 Select **Execute** after the confirmation message is displayed.

When saving has been completed, the screen from step 1 will be returned.



**Note** Never input the reset signal or turn OFF the power when processing messages are displayed. Data may be lost, and the V530-R150 may not operate properly the next time it is started.

5 Turn OFF the power for the V530-R150.

# SECTION 6

## Functions and Operations

This section gives details of the functions and operations possible with the V530-R150 2-Dimensional Code Reader, including the procedures necessary for communications with external devices.

6-1	Menu Registration .....
6-2	SET (Setting) Mode .....
6-2-1	Image Adjust-**** .....
6-2-2	Read QRCode .....
6-2-3	Read DataMatrix .....
6-2-4	Image Analysis .....
6-3	MON (Monitor) Mode .....
6-4	RUN Mode .....
6-5	System .....
6-5-1	Communications Method .....
6-5-2	Backup .....
6-5-3	Image Storage .....
6-5-4	Startup Mode .....
6-5-5	Multi Drop .....
6-5-6	Error Method .....
6-5-7	Version .....
6-6	Scenes .....
6-7	Saving to Flash Memory .....

## 6-1 Menu Registration

The V530-R150 has the five menu items shown below. The combination of these items is different according to the reading codes (QR Code or Data Matrix). Register items according to the following combinations and order. Reading is not performed correctly if items are registered in different combinations or orders. The menu items are registered in scenes.

### Reading QR Code

Scn 0=SET=

<b>0. Image Adjust-QR</b>
1.Read QRCode
2. Image Analysis

### Reading Data Matrix


Scn 0=SET=

<b>0. Image Adjust-DM</b>
1. Read DataMatrix
2. Image Analysis


---

**Procedure**

- 1 Enter the **SET** mode.



- 2 Move the cursor to **0.** and press the ENT Key.  
The selection of menus is displayed. When changing a registered menu, press the SHIFT + ESC Keys.



- 3 Move the cursor to the desired selection and press the ENT Key.

The menu is registered.



- 4 Register the menu items for **1.** and **2.** in the same way.
- If setting is made incorrectly, overwrite the setting with the correct one.
  - Perform scene clear when you want to clear all three scenes at once. → p. 158


## 6-2 SET (Setting) Mode

### 6-2-1 Image Adjust-\*\*\*\*

**SET** — **Image Adjust-QR**


**SET** — **Image Adjust-DM**

Set the shutter speed, filtering, and background suppression for reading.



When adjusting the image on the monitor, change to a through image. The through images taken by the Camera are displayed so that the image can be adjusted while monitoring.

Enter MON or RUN mode.




## Shutter Speed

The shutter speed can be changed according to the movement of the reading object.



### Procedure


- 1 Select **0.Image Adjust-\*\*\*\***.



- 2 Select **Shutter Speed**.



- 3 Select the appropriate shutter speed while monitoring the screen.



Press the ENT Key. The shutter speed at the cursor position will be set.


**Filtering**

Manipulates the image read by the Camera.




**Procedure**


- 1 Select **0.Image Adjust-\*\*\*\***.



- 2 Select **Filtering**.



- 3 Select the appropriate filtering method while monitoring the screen.



Press the ENT Key. The type of filtering at the cursor position will be saved.

**BGS Levels (Background Suppression)**



Background suppression (BGS) changes image areas with densities below the lower limit to 0, and image areas with densities above the upper limit to 255 so that only images with densities between the lower and upper limits are measured.

Lower limit: 150 Upper limit: 255





Image areas with densities of 149 or lower will not be read and the density will be changed to 0.


Only image areas with densities between 150 and 255 will be read. The whole image is graded from 0 to 255.

**Procedure**


- 1 Select **0.Image Adjust-\*\*\*\***.



- 2 Select **BGS Levels**.



3 Press the Left or Right Key to change the numeric value.



4 Move the cursor to **OK** to enter the setting.

## 6-2-2 Read QRCode


**SET** — **Read QRCode**

**Read QRCode** has the following four setting items.

Reading Settings	Sets the reading conditions for QR Codes.
Display Settings	Sets the items to be displayed on the screen in MON (monitor) and RUN modes.
Function Settings	Improves the accuracy of reading data.
Pattern Settings	Effective when <b>Pattern Search</b> is selected for FP search method.

**Reading Settings**

Sets the conditions for reading QR Codes.



①	Symbol Color	:	Black
②	Right&Left Reverse	:	OFF
③	Gray Edge Value	:	[32]
④	Number of Retries	:	0
⑤	FP Search Method	:	Normal

1 Select the color of symbol.

Black	Black symbol printed on white base.	
White	White symbol printed on black base. The image is black/white reversed and is input to image memory 0.	

2 Select whether Right & Left Reverse of QR Codes is necessary.

ON	Necessary For reading an image after reflection, or through the back of a transparent material, such as glass.
OFF	Unnecessary (Default setting) For normal reading (from the front of the object)

3 Set the black and white gray edge value. (Level: 1 to 127; Default setting: 32.) Set the gray edge value higher when the reflection ratio of black and white is high and set it lower when the ratio is low.


A function to calculate the ideal gray edge value automatically is available.

When setting reading conditions for the first time, be sure to use this function. → p. 102


- 4 Select the number of retries to be made if the reading is NG. (0 to 9; Default setting: 0.)
- 5 Select the FP search method. (Normal Search/Pattern Search; Default Setting: Normal)  
Select Normal under normal conditions. Select Pattern Search only under special conditions such as when the quality of printing (marking) of a 2-dimensional code is not good.

### Procedure


- 1 Select **1.Read QRCode**.



- 2 Select **Reading Settings**.




- 3 Set each item.



- 4 Select **Register** before leaving this screen.

## Display Settings

Sets the items to be displayed on the screen in MON (monitor) and RUN modes. The processing time becomes longer if more items are selected.



- 1 Select whether or not to display reading data for QR Codes on the screen. (The default setting is ON.)
- 2 Select whether or not to display detailed data of QR Codes on the screen. (The default setting is OFF.)  
If turned ON, information such as detailed information about codes and pixels per cell, etc. is displayed.
- 3 Select whether or not to display finder pattern positions of QR Codes on the screen. (The default setting is OFF.)
- 4 Select whether or not to display cell recognition positions of QR Codes on the screen. (The default setting is OFF.)

**Note** When *Read QRCode/Function Settings/Cell Verify* is set to ON, this function is invalid.

- 5 Select the font size of reading data to be displayed on the screen. (x1/x4; Default setting is x1.)  
When the displayed data exceeds the number of letters given below, the font size is automatically set to x1.


- 64 or more letters  
(x4 when reading accuracy or data history function is ON.)

Data other than reading data (detailed data etc.) is displayed with x1 font size regardless of this setting.


---

**Procedure**


- 1 Select **1.Read QRCode**.



- 2 Select **Display Settings**.




- 3 Set each item.



- 4 Select **Register** before leaving this screen.

**Function Settings**

Functions to improve the accuracy of data are available. There are restrictions on the combination of functions used. Consider the priority of functions when making settings.



**Note** Cell Verify can be used together with Judge Coincidence, Data History, Reading Accuracy and Judge Gray Value, but no other combination can be used together.

1 Cell Verify is a function that performs verification judgment by registering black and white information of cells as standard data.

When reading the same code continuously, surface defects can be checked for.

Set to **Register** to register black and white recognition of each cell and then set to **ON**.

OFF: No judgment is performed. (Default setting)

Register: Black and white recognition of each cell being read in the next trigger is registered as standard.

Verify: Every time reading is performed, the registered cell recognition is verified. If not verified, the section will be displayed on the screen.

Clr Data: Registered data is cleared.

**Note** When this function is used, the setting of **Read QRCode/Reading Settings/Cell Position** is invalid.

2 Judge Coincidence is a function that performs coincidence judgment of reading data.

Up to 4 standard data can be registered.

Select **Data** (0 to 3) to register the standard data and then set to **ON**.

OFF: No judgment is performed. (Default setting)

Data 0 to 3: The data read in the next trigger is registered as the number of standard data.

Verify: Every time reading is performed, the registered standard data and reading data are verified.  
The judgment result is output to terminal blocks (DO0 to 3) and RS-232C (Normal).

Clr Data: All registered data is cleared.

3 When Data History is turned ON, the following four items are counted and displayed on the screen.

The counted values are maintained even when the power is turned OFF if the data is saved to flash memory.

The values are cleared when OFF is selected. (The default setting is OFF.)

- Number of readings
- Number of OK readings
- Reading accuracy  
(Number of OK readings ÷ Number of readings × 100)
- Error codes

4 When Reading Accuracy is turned ON, one trigger performs ten readings.

The reading accuracy and the data from the 10th reading are displayed on a screen and output to RS-232C (Normal). (The default setting is OFF.)

5 Judge Gray Value is a function that measures the suitable gray edge value automatically.


If this function is turned ON, press TRIG on the console when in MON (monitor) or RUN mode to measure the gray edge value. The gray edge value is measured and reflected in the **Read QRCode/Reading Settings/Judge Gray Value** setting.

When setting reading conditions, use this function to set the gray edge value.


Turn OFF after setting the gray edge value. (The default setting is OFF.)

Procedure


- 1 Select **1.Read QRCode**.



- 2 Select **Function Settings**.



- 3 Set each item.



- 4 Select **Register** before leaving this screen.

**Pattern Settings**

Finder patterns may not be detected if the quality of the 2-dimensional code is bad or printed in dots.


If this is the case, select **Pattern Search** for FP search method.

The position for the code can be detected by searching the most similar part to a registered finder pattern called a model.



Reading may not be performed correctly if the angle with respect to the model is more than  $\pm 10^\circ$ . It should be in a range of approx.  $\pm 10^\circ$ .


**Note** Set to **Pattern Search** for FP search method in **Reading Settings** to perform pattern search.



- 1 Register finder patterns as a model.
- 2 The registered model can be confirmed on the video monitor.  
Confirm whether the model is registered correctly using Reference Model.
- 3 The region in which to search for the model can be specified.
- 4 Set the conditions for pattern search.
  - Correlation values for the model, etc.
  - Version information for the QR Code, etc.


**What is “Pattern Search”?**

Pattern search is a method to detect a finder pattern using a registered finder pattern called a model. Since the image pattern is registered, the position of the code can be detected with higher accuracy than when in normal mode even if the quality of the marking is bad.




**Model Registration**

Registers finder patterns as a model.




**Procedure**

- 1 Select **1.Read QRCode**.



- 2 Select **Pattern Settings**.




- 3 Select **Model Registration**.



- 4 Draw a box as the area in which to search for the model.


Specify the upper right and lower left coordinates.



Register a find pattern with a margin of approx. 0.5 cell.


### Reference Model

The registered model images can be displayed on a screen. After model registration, confirm whether the model has been registered correctly by performing Model Reference.




Procedure


- 1 Select **1.Read QRCode**.




- 2 Select **Pattern Settings**.



- 3 Select **Reference Model**.




Model images will appear.




**Search Region**

Specify the region in which to search for models.



**Procedure**

- 1 Select **1.Read QRCode**.




2 Select **Pattern Settings**.



3 Select **Search Region**.




4 Draw a box as the region in which to search for the model.  
Specify the whole screen under normal conditions.



Parameter


Sets the detail settings for pattern search.



①	Pixel Skipping X	: [ 4]
②	Pixel Skipping Y	: [ 4]
③	Correlation	: [ 30]
④	Finder Display	: All
⑤	Version	: 1
⑥	Grid	: Timing

**End**

- 1 Change the pixel skipping parameters used to search for a model. (1 to 20)  
 The processing time can be reduced if the pixel skipping parameters are set to larger values. However, depending on the image, the search may not be performed since the accuracy is reduced. After changing the setting, perform a search to confirm whether the search can be performed correctly.



- 2 Same as 1 above.
- 3 Set the correlation threshold value for detecting finder patterns.  
 Correlation values higher than the threshold are detected. (1 to 100)


- 4 Set the finder pattern display to all or one.  
All: All finder patterns detected are displayed.  
One: Only the finder pattern with the highest correlation value is displayed.
- 5 Set the version information for the QR Code to be read. (1 to 6)

**Note** If the wrong version information is set, the reading can not be performed correctly.


- 6 Set the method for cell recognition.  
Timing: Cell recognition is performed using a timing pattern.  
Cell: Cell recognition is performed using a registered model.

**Procedure**


- 1 Select **1.Read QRCode**.



- 2 Select **Pattern Settings**.



- 3 Select **Parameter**.



4 Set each item.

Pixel Skipping X	:	[ 4]
Pixel Skipping Y	:	[ 4]
Correlation	:	[ 30]
Finder Display	:	All
Version	:	1
Grid	:	Timing
<b>End</b>		

5 Select **End** before leaving this screen.

### 6-2-3 Read DataMatrix

**SET** — **Read DataMatrix**

Set the following three items under **Read DataMatrix**.

Reading Settings	Sets the conditions for reading Data Matrix codes.
Display Settings	Sets the items to be displayed on the screen in MON (monitor) and RUN modes.
Function Settings	Improves the accuracy of reading data.

#### Reading Settings

Sets the conditions for reading Data Matrix codes.

**SET** — **Read DataMatrix**  
     ↳ **Reading Settings**

①	Symbol Color	:	Black ▼
②	Right&Left Reverse	:	OFF ▼
③	Code Size	:	10 × 10 ▼
④	Gray Edge Value	:	[ 32]
⑤	Number of Retries	:	0 ▼
⑥	Length of Finder	:	[100]
⑦	Background Cut	:	Weak ▼
<b>Register</b>		<b>Cancel</b>	

1 Select the symbol color.

Black	Black symbol printed on white base.	
White	White symbol printed on black base.	

2 Select whether Right & Left Reverse of Data Matrix codes is necessary.

ON	Necessary For reading an image after reflection, or through the back of a transparent material such as glass.
OFF	Unnecessary (Default setting) For normal reading (from the front of the object).

3 Select the matrix size of codes.

(10 x 10 to 26 x 26; Default setting: 10 x 10)

4 Set the black and white density level. (Level: 1 to 127; Default setting: 32.) Set to 32 under normal conditions.

Set the density higher when the reflection ratio of black and white is high and set it lower when the ratio is low.

5 Select the number of retries to be made if the reading is NG.

(0 to 9; Default setting: 0.)

6 Input the length of finder patterns (L-shape) in pixels.

(50 to 480, Default setting: 100)

A function to measure L-shape length automatically is available.


When setting reading conditions for the first time, be sure to use this function. → p. 115

7 Select the BGS level to search for finder patterns (L-shape).


(Weak/Middle/Strong; Default setting: Weak)

Procedure


- 1 Select **1.Read DataMatrix**.



- 2 Select **Reading Settings**.



- 3 Set each item.



- 4 Select **Register** before leaving this screen.

Display Settings



Sets the items to be displayed on the monitor in MON (monitor) and RUN modes.

The processing time becomes longer if more items are selected.

①	Reading Data	:	ON	▼
②	Detail Data	:	OFF	▼
③	Finder Pattern	:	OFF	▼
④	Cell Position	:	OFF	▼
⑤	Font Size	:	x4	▼
<b>Register</b>		<b>Cancel</b>		

- 1 Select whether or not to display reading data for Data Matrix codes on the screen. (The default setting is ON.)
- 2 Select whether or not to display detailed data of Data Matrix codes on the screen. (The default setting is OFF.)  
If turned ON, information such as detailed information about codes and pixels per cell, etc. is displayed.
- 3 Select whether or not to display finder pattern positions of Data Matrix codes on the screen. (The default setting is OFF.)
- 4 Select whether or not to display cell recognition positions of Data Matrix codes on the screen. (The default setting is OFF.)

**Note** When **Read DataMatrix/Function Settings/Cell Verify** is set to ON, this function is invalid.


- 5 Select the font size of reading data to be displayed on the screen. (x1/x4; Default setting is x1.)  
When the displayed data exceeds the number of letters given below, the font size is automatically set to x1.
  - 64 or more letters  
(x4 when reading accuracy or data history function is ON.)

Data other than reading data (detailed data etc.) is displayed with x1 font size regardless of this setting.


---

**Procedure**


- 1 Select **1.Read DataMatrix**.



- 2 Select **Display Settings**.



- 3 Set each item.



- 4 Select **Register** before leaving this screen.

## Function Settings



Functions to improve the accuracy of data are available. There are restrictions on the combination of functions used. Consider the priority of functions when making settings.

①	Cell Verify	: OFF	▼
②	Judge Coincidence	: OFF	▼
③	Data History	: OFF	▼
④	Reading Accuracy	: OFF	▼
⑤	Measure L Length	: OFF	▼
		<b>Register</b>	Cancel

**Note** Cell Verify can be used together with Judge Coincidence, Data History, Reading Accuracy and Measure L Length, but no other combination can be used together.

1 Cell Verify is a function that performs verification judgment by registering black and white information of cells as standard data.

When reading the same code continuously, surface defects can be checked for.

Set to **Register** to register black and white recognition of each cell and then set to **ON**.

OFF: No judgment is performed. (Default setting)

Register: Black and white recognition of each cell being read in the next trigger is registered as standard.

Verify: Every time reading is performed, the registered cell recognition is verified. If not verified, the section will be displayed on the screen.

Clr Data: Registered data is cleared.

**Note** When this function is used, the setting of **Read Data-Matrix/Reading Settings/Cell Position** is invalid.

2 Judge Coincidence is a function that performs coincidence judgment of reading data.

Up to 4 standard data can be registered.

Select **Data** (0 to 3) to register the standard data and then set to **ON**.

OFF: No judgment is performed. (Default setting)

Data 0 to 3: The data read in the next trigger is registered as the number of standard data.

Verify: Every time reading is performed, the registered standard data and reading data are verified.

The judgment result is output to terminal blocks (DO0 to 3) and RS-232C (Normal).

Clr Data: All registered data is cleared.

3 When Data History is turned ON, the following four items are counted and displayed on the screen.

The counted values are maintained even when the power is turned OFF if the data is saved in flash memory.

The values are cleared when OFF is selected. (The default setting is OFF.)

- Number of readings
- Number of OK readings
- Reading accuracy  
(Number of OK readings ÷ Number of readings × 100)
- Error codes

4 When Reading Accuracy is turned ON, one trigger performs ten readings.

The reading accuracy and the data from the 10th reading are displayed on a screen and output to RS-232C (Normal). (The default setting is OFF.)


5 Measure L Length is a function that measures L length automatically.

If this function is turned ON, press TRIG on the console when in MON (monitor) or RUN mode to measure the L length. The L length is measured and reflected in the **Read DataMatrix/Reading Settings/Length of Finder** setting. When setting reading conditions, use this function to set the L length.

Turn OFF after setting the L length. (The default setting is OFF.)

Procedure


1 Select **1.Read DataMatrix**.



2 Select **Function Settings**.



3 Set each item.



4 Select **Register** before leaving this screen.

### 6-2-4 Image Analysis



The following five functions are available for image analysis. Use these functions when analyzing finder patterns or checking pixel values for cell recognition.

Display Pixel Value	Displays the density of a specific area in the range 0 to 255.
Line Bright X	The density distribution of a horizontal line is displayed in a graph.
Line Bright Y	The density distribution of a vertical line is displayed in a graph.
Image Magnifier	Magnifies the image in a specific area.
Measure Length	Measures the cell size in pixels.

**Display Pixel Value**

Displays the density information for a specific area.



Scn 0=SET=2.Image Analysis

Display Pixel Value

1



```

192 192 181 189 191 182 192 192 191 200 200 188 176 181 181 178
200 195 192 192 177 168 173 179 183 179 178 168 168 169 178168
188 189 194 193 176 162 145 151 137 130 135 152 147 135 131 132
190 180 192 186 176 115 66 77 70 72 66 66 78 67 66 79
204 195 182 176 175 107 60 44 43 45 42 50 46 46 47 46
199 187 178 165 166 95 56 49 43 38 37 38 39 41 41 41
192 175 174 181 174 104 50 44 38 45 41 35 45 39 42 46
191 191 183 179 177 100 53 37 37 36 44 40 46 42 48 48
195 180 176 174 174 110 53 43 38 42 45 44 59 62 57 55
187 183 195 197 175 95 56 43 39 38 44 72 104 131 120 130
186 194 188 186 168 111 52 44 41 47 52 112 147 156 158 161
189 182 177 180 180 109 61 45 40 42 54 136 167 176 176 177
197 184 176 154 158 91 51 42 53 42 46 123 160 184 178 184
193 182 169 180 162 93 52 40 40 44 46 48 136 167 176 176
185 185 177 175 162 100 58 40 39 40 51 133 168 177 180 168
187 193 181 175 166 91 54 38 39 41 46 108 157 166 174 180
          
```

2

```


192 192 181 189 191 182 192 192 191 200 200 188 176 181 181 178
200 195 192 192 177 168 173 179 183 179 178 168 168 169 178168
188 189 194 193 176 162 145 151 137 130 135 152 147 135 131 132
190 180 192 186 176 115 66 77 70 72 66 66 78 67 66 79
204 195 182 176 175 107 60 44 43 45 42 50 46 46 47 46
199 187 178 165 166 95 56 49 43 38 37 38 39 41 41 41
192 175 174 181 174 104 50 44 38 45 41 35 45 39 42 46
191 191 183 179 177 100 53 37 37 36 44 40 46 42 48 48
195 180 176 174 174 110 53 43 38 42 45 44 59 62 57 55
187 183 195 197 175 95 56 43 39 38 44 72 104 131 120 130
186 194 188 186 168 111 52 44 41 47 52 112 147 156 158 161
189 182 177 180 180 109 61 45 40 42 54 136 167 176 176 177
197 184 176 154 158 91 51 42 53 42 46 123 160 184 178 184
193 182 169 180 162 93 52 40 40 44 46 48 136 167 176 176
185 185 177 175 162 100 58 40 39 40 51 133 168 177 180 168
187 193 181 175 166 91 54 38 39 41 46 108 157 166 174 180
          
```

- 1 Specified area is 16 x 16 pixels.  
Use Up/Down/Left/Right Keys to move to the position for which density information is required.  
Press the SHIFT Key at the same time to move faster.
- 2 The density information for the specified area is displayed.


---

**Procedure**

- 1 Select **2.Image Analysis**.



- 2 Select **Display Pixel Value**.



- 3 Move to the required area by using Up/Down/Left/Right Keys.


The density information will be displayed.

Press the SHIFT Key at the same time to move faster.


- 4 Press the ESC Key to leave this screen.

### Line Bright (X), Line Bright (Y)


A graph indicating density distribution in a horizontal or vertical line is called "Line Bright."



- Line Bright X (fixed Y coordinate)




- Line Bright Y (fixed X coordinate)




- 1 Specify the beginning and end point of the line for which density distribution is to be displayed.
- 2 The density distribution is displayed.
- 3 The ratio of black and white with respect to the gray edge value is displayed.

**Procedure**


- 1 Select **2.Image Analysis**.



- 2 Select **Line Bright**.



- 3 Set the gray edge value level for black and white judgment.  
(1 to 127)




- 4 Select **Register**.  
The Line Bright is displayed.
- 5 Specify the beginning and end points.  
Move the cross cursor with Up/Down/Left/Right Keys and press the ENT Key.

- 6 To display a different area, repeat procedure 5 as required.
- 7 Press the ESC Key before leaving this screen.

## Image Magnifier


Magnifies the image in a specified area.




- 1 The specified area is 32 x 32 pixels (fixed).  
Use Up/Down/Left/Right Keys to move to the position to be magnified.  
Press the SHIFT Key at the same time to move faster.
- 2 The image in the specified area is magnified.

Procedure

- 1 Select **2.Image Analysis**.



- 2 Select **Image Magnifier**.




- 3 Move to the specified area using Up/Down/Left/Right Keys.  
Press the SHIFT Key at the same time to move faster.
- 4 Press the ENT Key.  
A magnified image is displayed within a dotted frame.

**Measure Length**

Measures the size of cells in pixels.

For stable reading, adjust the field of vision to be at least five pixels per cell.




- 1 Specify the beginning and end point of the line to be measured.
- 2 Pixels per cell in the QR Code is displayed.
- 3 Pixels per cell in the DataMatrix code is displayed.
- 4 The length of the dotted line in pixels is displayed.
- 5 The coordinates of the beginning point are displayed.
- 6 The coordinates of the end point are displayed.

---

**Procedure**

- 1 Select **2.Image Analysis**.



- 2 Select **Measure Length**.



- 3 Move the cross cursor to the beginning point using Up/Down/Left/Right Keys and press the ENT Key.  
Press the SHIFT Key at the same time to move faster.
- 4 Specify the end point in the same way.  
The length of the straight line is measured.
- 5 Press the ESC Key to leave this screen.

## 6-3 MON (Monitor) Mode


Confirms whether the reading can be correctly performed with the set conditions.

The reading judgment and data are not output to the terminal blocks or RS-232C but displayed on a monitor.

### Procedure


- 1 Enter MON (Monitor) mode.

MON (monitor) mode automatically moved to after leaving SET mode.




- 2 Input reading trigger.

- Console  
One reading is performed when the TRIG Key is pressed once.
- Terminal Block → p. 25
- RS-232C → p. 46, 52



Displayed Images. Press the SHIFT + Up/Down Keys to switch images.

**Types of Displayed Image**


<p>Freeze (□)</p>	<p>A still image immediately after measurement. The memory number (0 to 23) under which the image is stored is displayed in □. When reading moving objects, display freeze images.</p>
<p>Through</p>	<p>A live image from the Camera. When reading is performed on through images, a delay of 33.3 ms max. (depending on timing of command inputs) will occur before starting to load images.</p> 
<p>Memory □</p>	<p>A reading image stored in the past. The reading images which are coincident with image storage conditions are stored in memory 0 to 23. How to set storage conditions of images. → p. 149</p>
<p>Image 0</p>	<p>An image after filtering according to the settings in <b>Setting/Image Adjust</b>. Reading is performed on the image after filtering.</p>
<p>Image 1</p>	<p>An edge detection image for Data Matrix processing. (For a scene in which conditions are set for QR Codes, this will be same as the Image 0.)</p>

**Differences in Displayed Screens According to Settings in Reading\*\*\*\*/Display Settings**

**When Reading Data is ON:**

- OK: Reading data are displayed.
- NG: Error codes are displayed.


(e.g.) Reading OK



**When Detail Data is ON:**

Detailed data of reading codes are displayed.


(e.g.)



**When Finder Pattern is ON:**

A cross cursor will appear at the position recognized as a finder pattern.


(e.g.)



**When Cell Position is ON:**

A cross cursor will appear at the position recognized as a cell. However, when *Read QRCode/Function Settings/Cell Verify* is Verify, the cell recognition position is not displayed.


(e.g.)



**Differences in Displayed Screens According to Settings in Reading\*\*\*/Function Settings****When Cell Verify is Verify:**

A cross cursor will appear at the position not identified when verified with standard data. Even when **Read QRCode/Display Settings/Cell Position** is ON, the result of cell recognition verification is displayed.


(e.g.)



**When Judge Coincidence is ON:**

Performs coincidence judgment and the result is displayed.  
Turn OFF Data History, Reading Accuracy, Judge Gray Value and Measure L Length functions since they cannot be used together with Judge Coincidence.

(e.g.) Coincident with registered data 1 (Reading OK)




If not coincident with registered data 0 to 3, "NG: (Reading Data)" is displayed.

**When Data History is ON:**

The number of readings, OK readings, Reading Accuracy and the result of error counts are displayed. The count values are cleared when turned OFF.

Turn OFF the Judge Coincidence, Reading Accuracy, Judge Gray Value, and Measure L Length functions as they cannot be used together with the Data History function.

(e.g.)



Reading data  
(32 letters max. can be displayed.)

Error codes

Number of errors occurred

**When Reading Accuracy is ON:**

Ten readings are performed with one trigger and the result is displayed.

The reading accuracy cannot be counted for the continuous reading commands.

Turn OFF the Judge Coincidence, Data History, Judge Gray Value, and Measure L Length functions as they cannot be used together with the Reading Accuracy function.

(e.g.)

Scn 0 ▼ MON ▼ OK 2500ms

Freeze (15)

Accuracy : 80%(8/10)

ABCDE12345

E000(2)	E001(0)	E002(0)	E003(0)	E004(0)	
E010(0)	E011(0)	E012(0)	E013(0)	E020(0)	E030(0)


Reading data      Error codes      Number of the errors occurred  
(32 letters max. can be displayed.)

**When Judge Gray Value is ON: (Read QRCode only)**

A suitable gray edge value is measured by pressing the TRIG Key on the Console. The gray edge value is automatically entered in the setting for **Gray Edge Value** in **Read QRCode/Reading Settings**.

Turn OFF the Judge Coincidence, Data History, and Reading Accuracy functions as they cannot be used together with the Judge Gray Value function.

(e.g.)




**When Measure L Length is ON: (Read DataMatrix only)**

The length of L-shape is measured by pressing the TRIG Key on the Console.

The measurement value is automatically entered in the setting for **Length of Finder** in **Read DataMatrix/Reading Settings**.

Turn OFF the Judge Coincidence, Data History, and Reading Accuracy functions as they can not used along with Measure L Length.

(e.g.)




## 6-4 RUN Mode

Reading is performed under the setting conditions for the scene displayed.

Reading judgement and data are output to external devices. For details regarding the display items, refer to 6-3 MON (Monitor) Mode. → p. 129

### Procedure

- 1 Select RUN Mode.



- 2 Input reading trigger.

### Commands

- Console  
One reading is performed by pressing the TRIG Key once.
- Terminal Block → p. 25
- RS-232C → p. 46, 52

### Output Format

- Terminal Block → p. 25
- RS-232C → p. 46, 52

## 6-5 System

### 6-5-1 Communications Method

#### SYS — Communications

Sets communications methods when communicating to external devices via terminal blocks or RS-232C.

- When communicating in normal format via RS-232C:  
Set the communications method for **RS-232C** and **Normal**.
- When communicating with host link via RS-232C:  
Set the communication method for **RS-232C** and **Host link**.
- When inputting trigger or outputting reading results (OK/NG) to the OK/NG terminals on terminal blocks:  
Set the communications method for **Terminal block**.

#### RS-232C

#### SYS — Communications

└─ RS-232C

①	Baud rate	:	38400 bps ▼
②	Data length	:	8bit ▼
③	Parity bits	:	None ▼
④	Stop bits	:	1bit ▼
⑤	Header	:	None ▼
⑥	Footer	:	CR ▼
⑦	FCS	:	OFF ▼
⑧	Attach digit no.	:	OFF ▼
⑨	Mode	:	Normal ▼
<b>End</b>			

- 1 Select 2400, 4800, 9600, 19200, or 38400 (bps).  
(Default setting: 38400)
- 2 Select 7 or 8 (bits). (Default setting: 8)
- 3 Select None, Odd, or Even. (Default setting: None)
- 4 Select 1 or 2 (bits). (Default setting: 1)

- 5 Select None, STX, or ESC. (Default setting: None)
- 6 Select CR, LF, or CR+LF. (Default setting: CR)
- 7 Select OFF or ON. (Default setting: OFF)
- 8 Select OFF or ON. (Default setting: OFF)  
The number of digits are shown in bytes. A letter or a number is 1 digit.
- 9 Select Normal or Host link (Default setting: Normal)

## **Normal**

If **Normal** is selected for the communications mode, it is possible to communicate with host devices such as personal computers with normal format via RS-232C.




### **MON (Monitor) Mode**

Receives command inputs, but the reading results are not output.

### **RUN Mode**

Possible to input commands and output the reading results.



- 1 None: No flow control. (Default setting)
- RS/CS: The hardware performs flow control. Use a cable that connects the RS and CS signals of the V530-R150 and external device. Data is transferred when the CS signal from the external device is ON.
- Xon/off: The software performs flow control. Data is transferred according to the Xon/off codes from the external device.

Multi Drop: Select when using with multi drop. Turns on RS signals when data are transmitted.

**Note** When multi drop is selected, ***SYS/Multi drop*** is automatically set to ON.

- 2 Set the number of seconds (1 to 120 s) before a timeout error occurs. (Default setting: 5 s)

## Host Link

When ***Host link*** is selected for the communications mode, it is possible to communicate with host devices such as Programmable Controller with host link format via RS-232C.



### MON (Monitor) Mode

Receives command inputs, but the reading results are not output.

### RUN Mode


Possible to input commands and output the reading results.

①	Read area	:	I/O▼
②	Begin read word	:	[ 0]
③	Write area	:	I/O▼
④	Begin write word	:	[ 0]
⑤	PLC mode check	:	ON▼
<b>End</b>			

- 1 Select I/O, HR (holding relay), LR (link relay), DM (data memory), or None. If no read area is set, commands will not be automatically read from the Programmable Controller by executing the TXD instruction in the ladder program. (The default setting is I/O.)
- 2 Set the first word to read in area specified above (0 to 9995). (Default setting: 0)
- 3 Set the write area where the V530-R150 writes the result. Select I/O, HR (holding relay), LR (link relay), DM (data memory), or None (No writing). (The default setting is I/O.)
- 4 Set the first word to write in the area specified (0 to 9996). (Default setting: 0)

- 5 ON: Checks the mode of the Programmable Controller in MON (monitor) and RUN modes. Reading starts with MON (monitor) mode. (Error messages are displayed.)
- OFF: Sends the command to switch mode to the Programmable Controller in MON (monitor) and RUN modes and switch the mode to MON (monitor) mode forcibly.

## Terminal Block



- 1 Select a trigger mode for TRIG B.

Continuous (Default)	Performs continuous reading while the TRIG B terminal is turned ON. In this mode, the settings for reading accuracy and the number of retries are invalid with TRIG input.
Level trig (trigger)	Repeats reading until an OK (readable) reading judgment is output while the TRIG B terminal is ON. In the case of an NG (not readable) reading, the NG signal is output when the TRIG B is turned OFF.


- 2 Select whether the OK/NG terminal is turned ON for an OK reading or an NG reading. (The default is ON for NG.)
- 3 Set the output period for reading judgment. Set a value between 2.0 and 10,000.0 ms that is greater than the rising time + output time, and less than the reading interval. If the cycle is longer than the reading interval, the output timing will fall behind as the readings are repeated. (The default setting is 10.0 ms.)

- 4 Set the time from when the result is output to the terminal block to when the GATE signal is turned ON. This time is used to wait until the data output becomes stable. Set a time between 1.0 and 1000.0 ms that is longer than the delay time for the external device.  
(The default setting is 1.0 ms.)
- 5 Set the time during which the GATE signal is ON. Set a value between 1.0 and 1000.0 ms so that the external device can read the reading judgment. (The default setting is 5.0 ms.)


## Operational Procedures for RS-232C, Normal, Host Link and Terminal Block

### Procedure

- 1 Select *Communications*.



- 2 Select *RS-232C, Normal, Host link, or Terminal block*.



3 Set each item.

(e.g.) RS-232C


Baud rate	:	38400 bps	▼
Data length	:	8bit	▼
Parity bits	:	None	▼
Stop bits	:	1bit	▼
Header	:	None	▼
Footer	:	CR	▼
FCS	:	OFF	▼
Attach digit no.	:	OFF	▼
↑↓			
<b>End</b>			

4 Select **End** before leaving this screen.

## 6-5-2 Backup

### SYS — Backup

The following four setting data can be backed up to personal computers. This is a useful function for setting other devices with the same data. Backing up the setting data is recommended as a precaution against loss due to data damage or device malfunctions.



- 1 Back up the setting items of **Communications**, **Image Storage**, **Startup mode**, **Multi drop**, and **Error method** under **System Settings** to a personal computer.
- 2 Back up the setting items of **Image Input (\*\*)**, **Read (\*\*\*\*)**, and **Image Analysis** of each scene to a personal computer.
- 3 Back up system data and scene data 0 to 9 to a personal computer.
- 4 Back up memory images to personal computers with BMP format (\*.BMP).The images can be displayed on most per-

Personal computers as BMP is a common image format for Windows.

- Saving




- Loading




**Note** Never input the reset signal or turn OFF the power while saving or loading. Data may be lost, and the V530-R150 may not operate properly the next time it is started.

## Procedure

- 1 Select **Backup**.



- 2 Select the data to be loaded or saved.



- 3 Select **Load** or **Save**.



4 Select the number for scene data and image data.

- Scene No.  
(0 to 9)

Scn 0
Scn 1
Scn 2
Scn 3
Scn 4
Scn 5
Scn 6
Scn 7
↑ ↓

- Image Data  
(Memory 0 to 23,  
Image 0 to 1)

Mem 0
Mem 1
Mem 2
Mem 3
Mem 4
Mem 5
Mem 6
Mem 7
↑ ↓

5 Select **Execute** when the confirmation message is displayed.

(e.g.) When saving system data:

<b>Data will be saved.</b>
<b>System data</b>
<b>Execute</b> <b>Cancel</b>

## Operation Examples for Personal Computers

This section describes data transfer using the Hyper Terminal provided on Windows95/98 and Windows NT4.0 computers. In this example, a RS-232C cable is connected to the COM1 port of the computer. Alter the example to suit your communications software or COM port number.

Data transfer is performed with XMODEM (-CRC or -SUM) protocol method.

**Note** Do not turn OFF the power while a message is being displayed in any saving or loading operations. Data in memory may be destroyed, and the V530-R150 may not operate correctly the next time it is started.

### **Saving Data to a Personal Computer (V530-R150 → Personal Computer)**

#### **Procedure**

1 Connect the COM1 port on the computer and the V530-R150 using an RS-232 cable.

2 Make the V530-R150 communication settings.

The default communication settings are as shown in the following table. These settings can be normally used.

Item	Setting
Baud rate	38400 (bps)
Data length	8 (bit)
Parity bits	None
Stop bits	1 (bit)
Footer	CR

- 3 Start the Hyper Terminal program on the computer and make the following communication settings.

The same communication settings must be used on both the V530-R150 and the modem on the computer.

Item	Setting
Baud rate (B)	38400 (bps)
Data length (D)	8 (bit)
Parity bits	None
Stop bits	1 (bit)
Flow control	None (XMODEM protocol is used.)

- 4 Save data from the V530-R150.

The data transfer screen will be displayed.

Saving Data

- 5 Select **Transfer/Receive File** from the Hyper Terminal menu.

- Specify where the file is to be saved.
- Set the protocol to **Xmodem**.

- 6 Select **Receive** and input the file name.

The data will be transferred from the V530-R150 to the computer.

The V530-R150 generates a timeout error if no response is received from the external device within 30 seconds. An error message will be displayed, and the error terminal will turn ON.

### Loading Data From the Computer (V530-R150 ← Personal Computer)

#### Procedure

- 1 Follow steps 1 to 3 in the above procedure to connect the V530-R150 and the computer.
- 2 Select **Transfer/Send File** from the Hyper Terminal menu.
  - Select the file to be loaded.
  - Set the protocol to **Xmodem**.

3 Select **Send**.

The data transfer screen will be displayed.

## 4 Load data with V530-R150.

Data will be transferred from the computer to the V530-R150.

The V530-R150 generates a timeout error if no response is received from the external device within 30 seconds. An error message will be displayed, and the error terminal will turn ON.

### 6-5-3 Image Storage

#### SYS — Image storage

Selects whether to store the reading image or not. A maximum of 24 images can be stored.

**Note** The stored images are cleared when the power is turned OFF. Back up to a personal computer to keep the image data.  
→ p. 145



## 1 Select the conditions to store reading images.

None	No images are stored.
Only NG	Only NG (unreadable) images are stored.
All	All images are stored regardless of readable or unreadable.

## Procedure

1 Select **Image Storage**.

**Scn 0=SYS=**

System settings

Communications

Backup

**Image storage**

Startup mode

Multi drop

Error method

Version

2 Select the conditions.

Image storage: Only NG ▼

**End**

3 Select **End** before leaving this screen.

## 6-5-4 Startup Mode

**SYS** — **Startup mode**

Sets the scene number and mode to be displayed when the power is turned ON.

If the V530-R150 is set to start in RUN mode for the scene where the desired reading conditions are registered, reading can be started by simply turning the power ON. The default setting is as follows.

- Startup Scene: 0
- Startup Mode : MON

① — Startup Scene : Scn 0 ▼


② — Startup mode : MON ▼

**End**


- 1 Select the startup scene number. (0 to 9)
- 2 Select the startup mode. (SET, MON, or RUN)

### Procedure

- 1 Select **Startup mode**.



- 2 Select the startup scene number and startup mode.



- 3 Select **End** before leaving this screen.


### 6-5-5 Multi Drop

**SYS — Multi drop**


One host (personal computer or Programmable Controller) can communicate with more than one V530-R150 by connecting the RS-232C/RS-485 converter.

The unit number is attached to the prefix of all communication data so, set a different unit number for each V530-R150.

The multi drop function is used only when the communications method is normal.



**Note** Refer to the manual of the converter for the number of V530-R150 that can be connected.  
The number is different depending on the converter.




- 1 Select if connecting multi drop.  
If ON is selected, the reading result is not output to RS232C even when reading is performed.  
When the host sends polling commands, the result will be output.  
(The default setting is OFF.)

**Note** When this function is turned ON, the flow control in *SYS/Communications/Normal* is automatically set to *Multi drop*.


2 Set the Unit No. (0 to 31)

## Procedure

1 Select **Multi drop**.



2 Set each item.




3 Select **End** before leaving this screen.

## 6-5-6 Error Method

**SYS** — **Error method**

A V530-R150 does not perform reading while the BUSY terminal is ON even when TRIG A is input. Set whether or not to turn ON the ERR terminal if a trigger signal is sent while the BUSY termi-

nal is ON to inform the external device that the trigger has not been accepted.



1 ERR ON (Default setting)

Reading is not performed while the BUSY terminal is ON regardless of TRIG A input.


When TRIG A is input with the correct timing, the ERR terminal turns OFF.

OFF


ERR terminal does not turn ON when TRIG A is input while BUSY terminal is ON. Reading is not performed.

## Procedure

1 Select **Error method**.



2 Select the error system.




3 Select **End** before leaving this screen.

## 6-5-7 Version

**SYS** — **Version**

The model of the controller and the version of the software can be displayed.




- 1 The model is displayed.
- 2 The version and production date of the software are displayed.

**Procedure**

- 1 Select **Version**.

The version information is displayed.



- 2 Select **OK** before leaving this screen.




## 6-6 Scenes


The V530-R150 has 10 scenes.  
Set different reading conditions for each scene.

### Procedure

- 1 Display the basic screen.



- 2 Move the cursor to **Scn 0** and press the ENT Key.



- 3 Move the cursor to **Scn 1** and press the ENT Key.  
Scene 1 appears.  
The mode is maintained after changing the scene.  
(In this case, MON mode.)

## Copying Scene Data

### Procedure

- 1 Move the cursor to the desired scene number and press the SHIFT+ ESC Keys.

Scn 0	MON ▼	--- --ms
Scn 0		Freeze (2)
Scn 1		
Scn 2		
Scn 4		
Scn 5		
Scn 6		
Scn 7		
Scn 8		
↑ ↓		

- 2 Select **Copy**.

Copy
Clear


- 3 Move the cursor to the original scene number and select **Execute**.

Original scene :	Scn 0 ▼
Execute	Cancel

## Clearing Scene Data

### Procedure


- 1 Move the cursor to the scene number to be cleared and press the SHIFT + ESC Keys.



- 2 Select *Clear*.  
The confirmation message is displayed.



- 3 Select *Execute*.




## 6-7 Saving to Flash Memory

Be sure to save revised setting data to flash memory before power is turned OFF.


As the V530-R150 loads data from flash memory at startup, any new data be will lost if it is not saved to flash memory. Also, images in RAM are cleared when power is turned OFF.

### Procedure

- 1 Display the basic screen.




- 2 Move the cursor to **MON** (monitor) and press ENT.



- 3 Select **SAVE**.
- 4 Select **Execute** when the confirmation message is displayed.

When saving is completed, the screen in step 1 appears.



**Note** Never input the reset signal or turn OFF the power when processing messages are displayed. Data may be lost, and the V530-R150 may not operate properly the next time it is started.

# **SECTION 7**

## **Regular Inspections**

This section gives basic maintenance procedures and inspection items for the V530-R150 2-Dimensional Code Reader.

To maintain the V530-R150 in the best condition, perform the following regularly.

- Lightly wipe off dirt with a soft cloth.
- Clean the lens and indicators with a cloth for a lens or air brush.

Inspection Items	Details	Required Tools
Power Supply	The voltage measured at the power supply terminals on the terminal block must be 24 VDC (+10%, -15%).	Circuit Tester
Ambient Temperature	The operating ambient temperature inside the cabinet must be between 0 to +50°C.	Thermometer
Ambient Humidity	The operating ambient humidity inside the cabinet must be between 35 to +85%.	Hygrometer
Installation	Each cable connector must be correctly inserted and locked. The cameras must be firmly secured. The camera lens mounts must be firmly secured.	Phillips screw driver

- Note**
1. Turn OFF the power and take safety precautions before conducting inspections.
  2. Do not use thinners or benzene.

# SECTION 8

## Specifications/Dimensions


This section gives specifications and dimensions for the component parts of the V530-R150 2-Dimensional Code Reader.

- 8-1 V530-R150 2-Dimensional Code Reader Controller . .
- 8-2 Console . . . . .
- 8-3 Camera . . . . .
- 8-4 Cables . . . . .
- 8-5 Video Monitor . . . . .

# 8-1 V530-R150 2-Dimensional Code Reader Controller

**V530-R150E**  
**V530-R150EP**

(Unit: mm)




**Specifications**

	V530-R150E	V530-R150EP
Input/output type	NPN	PNP
Supply voltage	24 VDC (+10%, -15%)	
Current consumption	Approx. 0.5 A	
Insulation consumption	20 M $\Omega$ min. between all DC external terminals and GR terminal (at 100 VDC, with internal surge absorber removed.)	
Dielectric strength	1,000 VAC, 50/60 Hz between all DC external terminals and GR terminal (with internal surge absorber removed.)	
Leakage current	10 mA max.	
Noise resistance (common mode)	1500 Vp-p; pulse width: 0.1 $\mu$ s/1 $\mu$ s; rising time: 1ns pulse	
Vibration resistance	10 Hz to 150 Hz; single amplitude: 0.5 mm; maximum acceleration 70 m/s <sup>2</sup> 4 times for 8 minutes each in 3 directions	
Shock resistance	200m/s <sup>2</sup> 3 times each in 6 directions	
Ambient temperature	0°C to +50°C	
Ambient humidity	35% to 85% (with no condensation)	
Ambient environment	No corrosive gases	
Storage temperature	-25°C to +65°C	
Protection class	Class I (with protective conductor terminal)	
Degree of protection	IEC60529 IP20 (in-panel)	
Weight	Approx. 390 g (without cable)	

# 8-2 Console

## F150-KP




### Specifications

Vibration resistance	10Hz to 150 Hz; single amplitude: 0.15 mm
Shock resistance	196 m/s <sup>2</sup>
Ambient temperature	0°C to +50°C
Ambient humidity	35% to 85% (with no condensation)
Ambient environment	No corrosive gases
Storage temperature	-25°C to +65°C
Degree of protection	IEC60529 IP20 (in-panel)
Length	2 m
Minimum bending radius	75 mm
Weight	Approx. 135 g

# 8-3 Camera

## F150-S1



### Specifications

Supply voltage	12 VDC
Current consumption	Approx. 160 mA
Vibration resistance	10 Hz to 150 Hz; single amplitude: 0.5 mm (Max. acceleration: 70 m/s <sup>2</sup> ) 4 times for 8 min. in each 3 directions
Shock resistance	200m/s <sup>2</sup> 3 times each in 6 directions
Ambient temperature	0°C to +50°C
Ambient humidity	35% to 85% (with no condensation)
Ambient environment	No corrosive gases
Storage temperature	-25°C to +60°C
Weight	Approx. 70 g

**Performance**

Picture element	1/3" interline CCD (reading all pixels)
Effective pixels	659 x 494 (H x V)
Synchronization	External sync. via horizontal sync signal
Shutter speed	Electronic shutter: 1/100, 1/500, 1/2000, 1/10000 sec
Lens mounting	C mount

**8-4 Cables****F150-VS Camera Cable****Specifications**

Vibration resistance	10Hz to 150 Hz; single amplitude: 0.15 mm 4 times for 8 min. in 3 directions
Shock resistance	196m/s <sup>2</sup> 3 times each in 6 directions
Ambient temperature	0°C to +50°C
Ambient humidity	35% to 85% (with no condensation)
Ambient environment	No corrosive gases
Storage temperature	-25°C to +65°C
Length	3 m
Minimum bending radius	75 mm

**F150-VM Monitor Cable****Specifications**


Vibration resistance	10 to 150 Hz; single amplitude: 0.15 mm 4 times for 8 min. each in 3 directions
Shock resistance	196m/s <sup>2</sup> 3 times each in 6 directions
Ambient temperature	0°C to +50°C
Ambient humidity	35% to 85% (with no condensation)
Ambient environment	No corrosive gases
Storage temperature	-25°C to +65°C
Length	2 m
Minimum bending radius	50 mm

## 8-5 Video Monitor

This is the recommended monitor and is available from OMRON.

### F300-M09 (OMRON)

(Unit: mm)



### Specifications

Supply voltage	100 VAC
Current consumption	Approx. 300 mA
Vibration resistance	10 Hz to 150 Hz; single amplitude: 0.15 mm 4 times for 8 min. each in 3 directions
Shock resistance	196m/s <sup>2</sup> 3 times each in 6 directions
Ambient temperature	0°C to +40°C
Ambient humidity	10% to 90% (with no condensation)
Ambient environment	No corrosive gases
Storage temperature	-25°C to +65°C
Weight	Approx. 5.8 kg

### Performance

System	Number of scanning lines: 525 Horizontal frequency: 15.75 kHz Field frequency: 60 Hz
I/O impedance	75 Ω, high impedance (selectable)
I/O level and polarity	Image: 0.7 Vp-p, positive Synchronization: 0.3 Vp-p, negative
Screen size	123 mm (H) x 164 mm (W) , monochrome (light-holding)
Resolution	700 TV lines min. (at center)

# SECTION 9

## Troubleshooting

This section details errors that may occur with the V530-R150 2-Dimensional Code Reader and gives procedures for dealing with those errors.

9-1	Troubleshooting .....
9-2	Error Codes and Remedies .....
9-2-1	QR Code Reading .....
9-2-2	Data Matrix Reading .....

## 9-1 Troubleshooting

### Connection Errors

#### **The power indicator is not lit.**

- The power supply is not connected properly.
- The supply voltage is not 24VDC+10%/–15%.

#### **The video monitor is blank.**

- The power of the video monitor is not ON.
- The monitor cable is not connected properly.
- The video monitor is malfunctioning.

#### **Cannot make key inputs from the Console.**

- The Console cable is not correctly connected.

#### **Camera images do not appear on the screen.**

- The lens cap has not been removed.
- The camera cable is not properly connected.
- The lens diaphragm is opened or closed too far.
- The shutter speed is not suitable.
- The lighting method is not suitable.

#### **The images on the video monitor are not clear.**

- There is electrical noise entering from the power supply or cables.
- The monitor cable is not correctly connected.

#### **The images on the video monitor are hard to read.**

- Refer to the entry for the error code in *9-2 Error Codes and Remedies*. Change the setting conditions and adjust the camera and lighting.
- Confirm the image after filtering (noise cut etc.) in “Image 0.”  
→ p. 130

### Errors During Menu Operation

#### **The reading results are not displayed on the video monitor.**

- The V530-R150 is not in MON (monitor) or RUN mode.

### Terminal Block Errors

#### **Trigger signals (input signals) are not received.**

- The cables are not correctly wired.
- The signal line is disconnected.
- The V530-R150 is not in MON (monitor) or RUN mode.

**Signals cannot be output externally.**

- The trigger signal has not been input.
- The cables are not correctly wired.
- The signal line is disconnected.
- The V530-R150 is not in RUN mode.

**RS-232C Communications Errors**

**No communications are possible.**

- The cables are not correctly wired.
- The communications specifications do not match those of the external device.
- The communications mode was not selected under **SYS/Communications/RS-232C**.
- The V530-R150 is not RUN mode.

**The Unit operates well initially, but after a while there is no response from the V530-R150.**

- The reception buffer on the external device (e.g. computer) is full. Check that settings allow the data to be properly received.

**9-2 Error Codes and Remedies**

**9-2-1 QR Code Reading**

Error Code	Description	Remedy
E000	No finder patterns detected	No finder patterns were detected. <ul style="list-style-type: none"> <li>• Make sure that the image is displayed on the screen correctly.</li> <li>• Check the printing of the reading code. Three finder patterns in a corner may be stained or damaged.</li> </ul>
E001	Finder pattern detection error (Two patterns were not detected.)	Only one finder pattern was detected.(The other two patterns were not detected.) Check the printing of the reading code. Two finder patterns may be stained or damaged. The position of finder patterns can be confirmed on the video monitor when <b>Display Settings/Finder Pattern</b> is turned ON.
E002	Finder pattern detection error (One pattern was not detected.)	Only two finder patterns were detected. (One pattern was not detected.) One finder pattern may be stained or damaged. The position of finder patterns can be confirmed on the video monitor when <b>Display Settings/Finder Pattern</b> is turned ON.

Error Code	Description	Remedy
E003	Finder pattern detection error (The relative positioning is incorrect.)	Three finder patterns were detected. However, the relative positioning of the three finder patterns is incorrect. The code may be bent or part of the finder patterns may be stained or damaged. The position of finder patterns can be confirmed on the video monitor when <b>Display Settings/Finder Pattern</b> is turned ON.
E004	Finder pattern detection error (4 or more finder patterns were detected.)	Too many finder patterns (4 or more) were detected. Some of the finder patterns may be stained or damaged. The position of finder patterns can be confirmed on the video monitor when <b>Display Settings/Finder Pattern</b> is turned ON.
E010	Decode error (Tentative version calculation error)	Finder patterns may be bent. Make sure that the image is loaded and at least 5 pixels per cell are displayed. The number of pixels of any section on a screen can be checked under <b>Image Analysis/Measure Length</b> .
E011	Decode error (Format information error)	"Format information" in QR Codes may be stained or damaged. (Refer to the figure below.)
E012	Decode error	"Version information" in QR Codes is not correct.
E013	Decode error (Cell recognition error)	Codes were restored to correct errors, but not decoded correctly. Data of QR Codes may be stained or damaged.
E020	Decode error (No definition error)	The printing is in a special format and not defined for the V530-R150 (connection mode, etc.). Change the printing format.
E030	Pattern search NG	As a result of the pattern search, 32 or more proposed finder patterns were found. Make sure the image is displayed on the monitor correctly and check the registered mode.


**Common Check Items for Error Codes E000 to E004**

- When FP search method is **Normal**:  
 Make sure that the gray edge value settings are correct.  
 A suitable gray edge value will be set when **Read QRCode/Function Settings/Judge Gray Value** is turned ON.
- When FP search method is **Pattern Search**:  
 Make sure that the registered model is correct.  
 Make sure that the version of the code being set is correct.

**Confirming Pixels Per Cell**

When *Display Settings/Detail Data* is turned ON, the number of pixels per cell is displayed together with detail information if reading is OK. When reading is NG, confirm the number of pixels per cell under **2. Image Analysis/Measure Length**.

**QR Codes**



- 1 A margin of 4 or more cells around the code is required.
- 2 Format information of the code. (  There are four.)
- 3 Finder patterns (Symbols in three corners)
- 4 Parts other than 1 to 3 are data.

**9-2-2 Data Matrix Reading**

Error Code	Description	Remedy
E100	Finder pattern detection error (No candidate finder patterns)	No finder patterns were detected. Make sure that the image is displayed on the monitor correctly. Check the printing of the reading code. The finder patterns, especially the L-shaped ones, may be stained or damaged.
E110	Finder pattern detection error (No finder patterns were detected.)	No finder patterns were detected. Make sure that the image is displayed on the monitor correctly. Check the printing of the reading code. The finder patterns, especially the L-shaped ones, may be stained or damaged.


Error Code	Description	Remedy
E111	Finder pattern detection error (Only one finder pattern was detected.)	Only one line of finder patterns was detected. Make sure the image is displayed on the monitor correctly. Check the printing of the reading code. One of the L-shaped finder patterns may be stained or damaged. The position of finder patterns can be confirmed on the video monitor when <b>Display Settings/Finder Pattern</b> is turned ON.
E112	Finder pattern detection error (The relative positioning is incorrect.)	Two finder patterns (two lines) were detected. However, the relative positioning of the patterns is incorrect. The codes may be bent or part of the finder patterns may be stained or damaged. The L length (the length of finder patterns) set may be too long. The L length can be checked when <b>Function Settings/Measure L Length</b> is turned ON.
E120	Decode error (Timing pattern detection error)	Check the printing of the reading codes. The timing patterns in the X or Y directions may be stained or damaged. The matrix size may not be set correctly. The L length (the length of finder patterns) set may be too short. The L length can be checked when <b>Function Settings/Measure L Length</b> is turned ON.
E121	Decode error (Timing pattern detection error in X direction)	Check the printing of the reading code. The timing pattern in the X direction may be stained or damaged. Codes may be bent.
E122	Decode error (Timing pattern detection error in Y direction)	Check the printing of the reading code. The timing pattern in the Y direction may be stained or damaged. Codes may be bent.
E123	Decode error (Cell recognition error)	Codes were restored to correct errors, but not decoded correctly. Part of the codes may be stained or damaged.
E150	Decode error (No definition error)	The printing is in a special format and not defined for the V530-R150. Change the printing format. The codes may be bent, stained, or damaged.

**Common Check Items for Error Codes E120 to E122**

Check the gray edge value in **Reading Settings**.  
Refer to **Image Analysis/Line Bright** for whether the value is correct.

**Confirming Pixels Per Cell**

When **Display Settings/Detail Data** is turned ON, the number of pixels per cell is displayed together with detail information in MON (monitor) or RUN mode. When reading is NG, confirm the number of pixels per cell under **2. Image Analysis/Measure Length**.

**Data Matrix**

- 1 A margin of 4 or more cells around the code is required.
- 2 Timing patterns (The cross point between black and white.)
- 3 The L-shapes in the corners are finder patterns.
- 4 Parts other than 1 to 3 are data.

# Appendix A

## ASCII Codes

Character	Data (Hexadecimal No.)						
NUL	00	SP	20	@	40	'	60
SOH	01	!	21	A	41	a	61
STX	02	"	22	B	42	b	62
ETX	03	#	23	C	43	c	63
EOT	04	\$	24	D	44	d	64
ENQ	05	%	25	E	45	e	65
ACK	06	&	26	F	46	f	66
BEL	07	'	27	G	47	g	67
BS	08	(	28	H	48	h	68
HT	09	)	29	I	49	i	69
LF	0A	*	2A	J	4A	j	6A
VT	0B	+	2B	K	4B	k	6B
FF	0C	,	2C	L	4C	l	6C
CR	0D	-	2D	M	4D	m	6D
S0	0E	.	2E	N	4E	n	6E
S1	0F	/	2F	O	4F	o	6F
DLE	10	0	30	P	50	p	70
DC1	11	1	31	Q	51	q	71
DC2	12	2	32	R	52	r	72
DC3	13	3	33	S	53	s	73
DC4	14	4	34	T	54	t	74
NAK	15	5	35	Y	55	u	75
SYN	16	6	36	V	56	v	76
ETB	17	7	37	W	57	w	77
CAN	18	8	38	X	58	x	78
EM	19	9	39	Y	59	y	79
SUB	1A	:	3A	Z	5A	z	7A
ESC	1B	;	3B	[	5B	{	7B
FS	1C	<	3C	\	5C		7C
GS	1D	=	3D	]	5D	}	7D
RS	1E	>	3E	^	5E	(~)	7E
US	1F	?	3F	-	5F	DEL	7F

# Appendix B

## FCS Check Program Examples (BASIC)

### Calculation Examples for Sending FCS

DATA\$	Sample Data Line
L	Data Length
CODE\$	Data Character
A	Exclusive Operation

```

100 *****CALCULATE FCS*****
110 '*FCSSET
120 L=LEN(DATA$)
130 A=0
140 FOR J=1 TO L
150 CODE$=MID$(DATA$,J,1)
160 A=ASC(CODE$)XOR A
170 NEXT J
180 FCS$=HEX$(A)
190 IF LEN(FCS$)=1 THEN FCS$="0"+FCS$
200 RETURN

```

### FCS Check Sub Routine Examples for Received Data

```

1000 *****FCSHECK*****
1010 '*FCSHECK
1020 Q=0:FCSCK$="OK"
1030 PRINT RESPONSE $
1040 LENG$=LEN(RESPONSE$)-3
1050 FCSP$=MID$(RESPONSE$,LENG$+1,2) .....Response Data of FCS
1060 FOR J=1 TO LENG$ .....Calculation Range of FCS
1070 Q=ASC(MID$(RESPONSE$,J,1))XOR Q
1080 NEXT J
1090 FCSD$=HEX$(Q)
1100 IF LEN(FCSD$)=1 THEN FCSD$="0"+FCSD$ .FCS calculated in a program
1110 IF FCSD$ < > FCSP$ THEN FCSCK$="ERR"
1120 PRINT "FCSD$=";FCSD$;"FCSP$=";FCSP$;
"FCSCK$=";FCSCK$; .....FCS correctly received :OK
1130 RETURN          FCS not received correctly:ERR

```

# Appendix C


## Data Capacity Tables

### QR Code

#### QR Code (Model 2)

The relation between matrix size (number of cells) and data capacity is shown in the table below.

In this example, the matrix size is 29 × 29 cells.




Matrix size (Version)	Error correction level	Data capacity		Matrix size (Version)	Error correction level	Data capacity	
		Num. Cap.	Alpha Num. Cap.			Num. Cap.	Alpha Num. Cap.
<b>21 × 21 (Version 1)</b>	L (7%)	41	25	<b>33 × 33 (Version 4)</b>	L (7%)	187	114
	M (15%)	34	20		M (15%)	149	90
	Q (25%)	27	16		Q (25%)	111	67
	H (30%)	17	10		H (30%)	82	50
<b>25 × 25 (Version 2)</b>	L (7%)	77	47	<b>37 × 37 (Version 5)</b>	L (7%)	255	154
	M (15%)	63	38		M (15%)	202	122
	Q (25%)	48	29		Q (25%)	144	87
	H (30%)	34	20		H (30%)	106	64
<b>29 × 29 (Version 3)</b>	L (7%)	127	77	<b>41 × 41 (Version 6)</b>	L (7%)	322	195
	M (15%)	101	61		M (15%)	255	154
	Q (25%)	77	47		Q (25%)	178	108
	H (30%)	58	35		H (30%)	139	84

# Data Matrix

## Data Matrix (ECC200)

The relation between matrix size (number of cells) and data capacity is shown in the table below.

In this example, the matrix size is  $22 \times 22$  cells.



Matrix size	Maximum data capacity	
	Num. Cap.	Alpha Num. Cap.
$10 \times 10$	6	3
$12 \times 12$	10	6
$14 \times 14$	16	10
$16 \times 16$	24	16
$18 \times 18$	36	25
$20 \times 20$	44	31
$22 \times 22$	60	43
$24 \times 24$	72	52
$26 \times 26$	88	64

# Index

## Numbers

2-dimensional code,

## A

applications, overview,

ASCII codes,

## B

back lighting,

background cut,

background suppression. *See* BGS levels

backup,

BGS levels,

## C

cables, ,  
    precautions,  
    specifications/dimensions,

Camera  
    mounting,  
    precautions,  
    specifications/dimensions,

CCTV lens. *See* lens

cell position, , ,

Cell Verify, , ,

clearing, scene data,

coaxial lighting,

code size,

commands, ,  
    Continuous Reading, ,  
    One Shot Reading, , ,  
    Read the Scene Number Currently Displayed, , ,  
    Request to Resend Scene Data,  
    Switch the Scene, , ,  
    Switch the Scene Number +1,  
    Switch the Scene Number -1,

communications  
    errors,  
    Host Link mode, ,  
    RS-232C,  
    Normal mode, ,  
    settings,  
    terminals blocks,

conditions, for reading,

connections,  
    errors,  
    Host Link mode,  
    Normal mode, ,  
    overview,  
    RS-232C,

connector,

Console,  
    keys,  
    specifications/dimensions,

continuous mode, timing,

continuous reading,

Controller  
    mounting/removing,  
    specifications/dimensions,

copying, scene data,

crimp terminals. *See* terminals

## D

data  
    capacity,  
    clearing scene data,  
    copying scene data,  
    loading,  
    saving,

Data History, , ,  
Data Matrix codes  
  data capacity,  
  menu tree,  
  reading, ,  
  errors,  
detail data, , ,  
dimensions,  
DIN Track, mounting,  
display, ,  
  *See also* images  
  settings  
    Data Matrix codes,  
    QR Codes,  
Display Pixel Value,

## E

edges, enhancing,  
errors  
  error codes, , ,  
  error method,  
  troubleshooting,  
Extension Tube,

## F

FCS  
  calculation,  
  program examples,  
features,  
filtering,  
finder pattern, , ,  
flash memory,  
flat surface, mounting,  
font size, ,  
FP search method,  
freeze images,  
functions, ,  
  overview,  
  settings, ,

## G-I

gray edge value, ,  
grounding,  
Host Link communications,  
  *See also* modes  
Image Magnifier,  
images,  
  adjusting,  
  image analysis,  
  Image Magnifier,  
  image types,  
  storage,  
inputs, ,  
  input commands. *See* commands  
  input specifications,  
  input terminals, , ,

inspections,  
installation,  
  precautions, ,

## J

Judge Coincidence, , ,  
Judge Gray Value, ,

## K-L

keys. *See* Console keys  
length of finder,  
lens,  
lighting,  
Line Bright,  
line speed,  
loading,

## M

Measure L Length, ,  
Measure Length,  
memory, images,  
menu  
  operations,  
    errors,  
    registration,  
    tree,  
model  
  reference,  
  registration,  
modes  
  at startup, ,  
  Host Link mode, ,  
  MON (monitor) mode,  
  Normal mode, ,  
  overview,  
  RUN mode,  
  SET mode,  
  trigger,  
multi drop,

## N

nomenclature,  
Normal communications,  
  *See also* modes  
number of retries, , ,

## O

oblique lighting,  
one shot mode, timing,  
operations, ,  
outputs,  
  output format, ,  
  output specifications,  
  output terminals, , ,  
overview,

## P

parameter,  
pattern  
  search,  
  settings,  
peripheral devices, connections,  
personal computer, connections,  
power supply,  
  wiring,  
precautions  
  general,  
  installation,  
processing time, calculating,  
Programmable Controller, connections,

## Q

QR Codes  
  data capacity,  
  menu tree,  
  reading, ,  
    errors,  
quitting,

## R

Read DataMatrix,  
Read QRCode,  
reading  
  checking,  
  conditions, ,  
  level trigger,  
  moving objects,  
  performing, ,  
  settings  
    Data Matrix codes,  
    QR Codes,  
Reading Accuracy, , ,  
reading data, , ,  
reference model,  
reflected lighting,

region, specifying,  
registration,  
Right&Left Reverse, ,  
ring lights,  
RS/CS, connections,  
RS-232C,  
    communications,

## **S**

saving,  
    to flash memory,  
scene data. *See* data  
scenes,  
search region,  
shutter speed,  
smoothing,  
specifications, , ,  
    power supply,  
    RS-232C,  
    terminals blocks,  
startup, ,  
storing,  
symbol color, ,  
system,  
    examination,

## **T**

tact time,  
terminal blocks,  
    communications,  
    errors,  
terminals, , ,  
    DO terminals,  
    input terminals, ,  
    OK/NG terminal,  
    output terminals, , ,  
    precautions,  
through images,  
timing,  
Trigger inputs. *See* inputs  
troubleshooting,  
TXD instructions,

## **V**

version,  
video monitor  
    precautions,  
    specifications/dimensions,

## **W**

wiring  
    Host Link mode,  
    Normal mode, ,  
    power supply,  
    RS-232C,

# Revision History

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.

Cat. No. Z136-E1-1



The following table outlines the changes made to the manual during each revision. Page numbers refer to the previous version.

Revision code	Date	Revised content
1	July 1999	Original production

**OMRON CORPORATION**

Industrial Automation Company

Advanced Sensors Division  
Sensing Devices and Components Division H.Q.  
28th Fl., Crystal Tower Bldg.,  
1-2-27, Shiromi, Chuo-ku,  
Osaka 540-6028 Japan  
Phone: (81)6-6949-6105/Fax: (81)6-6949-6149

**Regional Headquarters**

**OMRON EUROPE B.V.**

Wegalaan 67-69, NL-2132 JD Hoofddorp  
The Netherlands  
Tel: (31)2356-81-300/Fax: (31)2356-81-388

**OMRON ELECTRONICS, INC.**

1 East Commerce Drive, Schaumburg, IL 60173  
U.S.A.  
Tel: (1)847-843-7900/Fax: (1)847-843-8568

**OMRON ASIA PACIFIC PTE. LTD.**

83 Clemenceau Avenue,  
#11-01, UE Square,  
Singapore 239920  
Tel: (65)835-3011/Fax: (65)835-2711

**OMRON (CHINA) CO. LTD.**

21F, Beijing East Ocean Center  
No. 24A Jian Guo Men Wai Da Jie  
Chao Yang District, Beijing, 100022  
China  
Tel: (86)10-6515-5778/Fax: (86)10-6515-5810

# OMRON

**Authorized Distributor:**

Cat. No. Z136-E1-1

V530-R150 2-Dimensional Code Reader OPERATION MANUAL

**OMRON**