

停产产品

MACRO8/16



3-3719C0-0A0□-□00000



推荐的替代产品

UMAC 1020 CPU +ACC-5E3

3-4112A□U-□□0-B000□□
+
3-4017A-00-□00□-□1□□

■ 订货截止日期

2025年3月底

■ 装货截止日期

2025年9月底

■ 维修对应截止日期

2028年9月底

■ 与停产产品的异同点

推荐的替代产品型号	本体的颜色	外形尺寸	配线连接	安装尺寸	额定规格和性能	动作特性	操作方法
3-4112A□U-□□0-B000□□ + 3-4017A-00-□00□-□1□□	—	×	×	×	×	×	×

◎：通用

○：几乎无更改/高相似度的更改




×：更改较大

—：无相应规格

■ 停产产品与推荐的替代产品

停产产品	推荐的替代产品
3-3719C0-0A02-B00000	下述产品组合 3-4112AEU-200-B00000+3-4017A-00-A001-B100 有关详情，请咨询经销商。
3-3719C0-0A02-F00000	
3-3719C0-0A03-B00000	
3-3719C0-0A03-F00000	

关于替代产品

停产产品 3-3719C0-0A0□-□00000	推荐的替代产品 3-4112A□U-□□0-B000□□ + 3-4017A-00-□00□-□1□□
MACRO8/16 	安装UMAC1020 CPU和ACC-5E3需要两个底板插槽。 UMAC 1020 CPU  ACC-5E3 

■ 参考资料

UMAC 1020 CPU Part Number

Part Number Designation

Power UMAC 2 CORE ARM CPU

(A) (B) (C) (D) (E) (F) (G) (H) (K) (L)

3	-	4	1	1	2	A		U	-			0	-	B	0	0	0		
---	---	---	---	---	---	---	--	---	---	--	--	---	---	---	---	---	---	--	--

(A)

A - Dual-Core 1GHz ARM CPU

(B)

A - 1 GB RAM & 1 GB Flash
E - 2 GB RAM & 4 GB Flash

(D)

2 - 2 RJ45 Ethernet Ports OR
(1 EtherNet & 1 EtherCAT Port***) (E)
4 - PCIe** & 2 RJ45 Ethernet Ports OR
(1 EtherNet & 1 EtherCAT Port***) (E)

(G) (H)

B0 - 1 SLOT Black Front, Top and Bottom plates

Plate Option

(C)

U - UMAC Option with (30U-604147-10X)

Format Option

(E)

0 - No EtherCAT
1 - EtherCAT I/O Only
2 - EtherCAT 4 Servo Axes and I/O
3 - EtherCAT 8 Servo Axes and I/O
5 - EtherCAT 16 Servo Axes and I/O
9 - EtherCAT 32 Servo Axes and I/O

For more than 32 Servo Axes call factory

EtherCAT Options
Requires EtherCAT Port Option From

(K) (L)

00 - No Additional* Options
xx - Factory assigned digits
for Additional* Options

Factory Assigned Options

** This Option May require additional plates

*** For EtherCAT option requires selection from (E)

ACC-5E3 Part Number

UMAC ACC-5E3

(E) (H) (I) (K) (L)

3	-	4	0	1	7	A	-	0	0	-		0	0		-		1		
---	---	---	---	---	---	---	---	---	---	---	--	---	---	--	---	--	---	--	--

(E)

A - Fiber-Optic MACRO Transceiver
C - RJ-45 MACRO Connector

MACRO Communication Options

(H)

1 - 32-Node MACRO ASIC
2 - 64-Node MACRO ASIC

MACRO Node Options

(I)

B - BLACK Front, top and bottom plates (Standard)
F - BLACK Front plate only
Order as Spare Only

Plate Options

(K) (L)

00 - No Additional* Options
xx - Factory assigned digits
for Additional* Options

Factory Assigned Options

* If Any Additional Option is required, contact factory for digits K and L (Factory Assigned digits).

本指南中记载的规格为发布时的最新内容。规格等如有变更，恕不另行通知。

本指南内记载了主要规格上的更改内容。有关使用注意事项等使用时必须了解的内容，请务必阅读产品目录、规格书、使用说明书和手册。